

# WEST

## Installation Guide 2026



**DHI A/S headquarters**

Agern Allé 5  
DK-2970 Hørsholm  
Denmark

+45 4516 9200 Telephone

[mike@dhigroup.com](mailto:mike@dhigroup.com)

[www.mikepoweredbydhi.com](http://www.mikepoweredbydhi.com)

Company Registration No.: DK36466871

## PLEASE NOTE

### COPYRIGHT

This document refers to proprietary computer software, which is protected by copyright. All rights are reserved. Copying or other reproduction of this manual or the related programs is prohibited without prior written consent of DHI A/S (hereinafter referred to as "DHI"). For details please refer to your 'DHI Software Licence Agreement'.

### LIMITED LIABILITY

The liability of DHI is limited as specified in your DHI Software License Agreement:

In no event shall DHI or its representatives (agents and suppliers) be liable for any damages whatsoever including, without limitation, special, indirect, incidental or consequential damages or damages for loss of business profits or savings, business interruption, loss of business information or other pecuniary loss arising in connection with the Agreement, e.g. out of Licensee's use of or the inability to use the Software, even if DHI has been advised of the possibility of such damages.

This limitation shall apply to claims of personal injury to the extent permitted by law. Some jurisdictions do not allow the exclusion or limitation of liability for consequential, special, indirect, incidental damages and, accordingly, some portions of these limitations may not apply.

Notwithstanding the above, DHI's total liability (whether in contract, tort, including negligence, or otherwise) under or in connection with the Agreement shall in aggregate during the term not exceed the lesser of EUR 10.000 or the fees paid by Licensee under the Agreement during the 12 months' period previous to the event giving rise to a claim.

Licensee acknowledge that the liability limitations and exclusions set out in the Agreement reflect the allocation of risk negotiated and agreed by the parties and that DHI would not enter into the Agreement without these limitations and exclusions on its liability. These limitations and exclusions will apply notwithstanding any failure of essential purpose of any limited remedy.

# CONTENTS

## WEST Installation Guide

<b>1</b>	<b>Introduction</b>	<b>2</b>
<b>2</b>	<b>Installation Prerequisites</b>	<b>3</b>
<b>3</b>	<b>WEST Installation/Upgrade</b>	<b>4</b>
<b>4</b>	<b>DHI License Manager</b>	<b>8</b>
<b>5</b>	<b>Optional installation and use of external compiler</b>	<b>10</b>
5.1	Visual Studio Community 2022 (or later) Installation	10
5.2	Use of alternative compiler	12

## 1 Introduction

This installation guide covers the installation of WEST 2026 and required 3<sup>rd</sup> party software.

WEST 2026 is available as 64-bit version.

This guide describes the installation process for all the different deployment patterns and required associated 3<sup>rd</sup> party software.

**Important information:** Please be aware that all MIKE software (including the DHI License Manager) on the same computer must be installed with the same version. This is due to the dependencies between MIKE software products and our wish to use the latest and technically most advanced development systems.

## 2 Installation Prerequisites



WEST 2026 depends on some prerequisites as listed below:



1. Fully supported Windows operating systems:
  - Windows 11 Pro, version 23H2 (64 bit)
  - Windows 10 Pro, version 22H2 (64 bit)
  - Windows Server 2022, version 21H2
2. The DHI License Management application, to be downloaded and installed separately.
3. Microsoft .NET framework 4.7.2 or later




## 3 WEST Installation/Upgrade


WEST 2026 is installed by running the *Setup.exe* program included in the installation package.

The installation of the WEST is simple and requires no user interactions beyond accepting the license conditions and specifying the installation folder. The following table outlines the installation steps for WEST 2026.

Installation step	Screen
<p>Run the <i>setup.exe</i> file from the installation media/download folder.</p> <p><i>Note: Refer to the installation guide of the DHI License Manager for more information about features and license configuration.</i></p>	
<p><b>Click Next</b></p> <p>Accept the license agreement</p>	



Installation step	Screen
<p><b>Select</b> the components to install.</p> <p><i>Note: If desired, the user can select a different destination folder than the default one by clicking "Change"</i></p> <p><b>Click Next</b></p>	
<p><b>Select</b> the type of license available</p> <p><i>Demo/Unchanged:</i> If the installation relies on a pre-existing license, or for testing of the software without a license. Selecting this method is the easiest for installation, as the license can be configured later, see DHI License Manager, in Chapter 4 below.</p> <p><i>Internet:</i> Configuring an internet license using a connection file, or connection string, requires DHI License Manager to already be installed.</p> <p><i>Network:</i> Configuring an internet license using host name and port, requires DHI License Manager to already be installed.</p> <p><b>Click Next</b></p>	


Installation step	Screen
<p><b>If 'Internet' is selected:</b> provide either a connection file, or a connection string to the DHI Internet License Server.</p> <p><b>Click Next</b></p>	
<p><b>If 'Network' is selected:</b> provide the host IP address or DNS address and port of the license server.</p> <p><b>Click Next</b></p>	
<p><b>Launch the installation</b></p> <p><b>Click Install</b></p>	

Installation step	Screen
<b>Click Finish</b>	

## 4 DHI License Manager

The DHI license is handled through the DHI License Management software, which is installed by running the *Setup.exe* program included in the DHI License installation package.

Installation step	Screen
<b>Run</b> the <i>setup.exe</i> file from the installation media/download folder.	
<b>Accept</b> the license agreement	
<b>Once installed, Open</b> the DHI License Management program in the start menu as <b>administrator</b> ( <i>right click and select the option 'Run as Administrator'</i> )	



Installation step	Screen										
<p>There are three options:</p> <ul style="list-style-type: none"> <li>• Unlicensed demo mode</li> <li>• Internet Server</li> <li>• Network Server</li> </ul> <p>User-specific license details will be sent to users from DHI Entitlement Portal.</p> <p>Click the <b>Help</b> button, for more information or contact your local MIKE Sales representative.</p>	 <p>DHI License Manager</p> <p>Define the location from where your MIKE software will obtain a license</p> <p>License Server Setup</p> <p><input type="radio"/> Unlicensed demo mode</p> <p><input checked="" type="radio"/> Internet Server - your company's online license server</p> <p>Producer ID: <input type="text"/></p> <p>Server Domain: <input type="text"/></p> <p>Server ID: <input type="text"/></p> <p>User Key: <input type="text"/></p> <p><input type="radio"/> Network Server - a license server located on the company network</p> <p>Protocol: <input type="text"/> Port ID: <input type="text"/></p> <p>Host: <input type="text"/></p> <p><input type="radio"/> Local Server - a network server located on this computer</p> <p>Available Modules on your selected License Server</p> <table border="1"> <thead> <tr> <th>Module</th> <th>Version</th> <th>Free Seats</th> <th>Max Seats</th> <th>Expire date</th> </tr> </thead> <tbody> <tr> <td> </td> <td> </td> <td> </td> <td> </td> <td> </td> </tr> </tbody> </table> <p>Connect      Close</p>	Module	Version	Free Seats	Max Seats	Expire date					
Module	Version	Free Seats	Max Seats	Expire date							

## 5 Optional installation and use of external compiler

The default compiler included in the WEST installer is Zig but the user has the option to install and activate a different compiler such as Microsoft Visual C++ (VC++) compiler, which is available as part of Visual Studio Community 2022 (or later) suite.

### 5.1 Visual Studio Community 2022 (or later) Installation

Download Visual Studio Community from <https://visualstudio.microsoft.com/downloads/> and launch the installation by running `vs_community.exe`.


Instructions	Screen
<p>Read Privacy Statement and accept License Terms.</p> <p><i>Disclaimer: by accepting Microsoft Software License Terms, the user confirms to comply with terms of use of Visual Studio Community products as 3<sup>rd</sup> party components.</i></p> <p><i>License terms can also be found here:</i> <a href="https://visualstudio.microsoft.com/license-terms/mlt031819/">https://visualstudio.microsoft.com/license-terms/mlt031819/</a></p>	
<p>Select the workload <b>Desktop development with C++</b></p> 	

Instructions	Screen
<p>In the Installation Details (right hand panel) <b>select all</b> Optional features available to ensure installation of build tools and Windows SDK</p> <p><b>Click Install</b></p>	<p><b>Installation details</b></p> <p>▼ <b>Desktop development with C++</b></p> <ul style="list-style-type: none"> <li>▼ Included           <ul style="list-style-type: none"> <li>✓ C++ core desktop features</li> </ul> </li> <li>▼ Optional           <ul style="list-style-type: none"> <li><input checked="" type="checkbox"/> MSVC Build Tools for x64/x86 (Latest)</li> <li><input checked="" type="checkbox"/> C++ ATL for x64/x86 (Latest MSVC)</li> <li><input checked="" type="checkbox"/> C++ Build Insights</li> <li><input checked="" type="checkbox"/> Just-In-Time debugger</li> <li><input checked="" type="checkbox"/> C++ profiling tools</li> <li><input checked="" type="checkbox"/> C++ CMake tools for Windows</li> <li><input checked="" type="checkbox"/> Test Adapter for Boost.Test</li> <li><input checked="" type="checkbox"/> Test Adapter for Google Test</li> <li><input checked="" type="checkbox"/> IntelliCode</li> <li><input checked="" type="checkbox"/> MSVC AddressSanitizer</li> <li><input checked="" type="checkbox"/> Windows 11 SDK (10.0.26100.7175)</li> <li><input checked="" type="checkbox"/> vcpkg package manager</li> <li><input checked="" type="checkbox"/> GitHub Copilot</li> <li><input checked="" type="checkbox"/> GitHub Copilot app modernization</li> <li><input type="checkbox"/> C++ MFC for x64/x86 (Latest MSVC)</li> </ul> </li> </ul> <p><b>Remove out-of-support components</b></p> <p>Total space required 12,02 GB</p> <p>Install while downloading ▾ <b>Install</b></p>

Once the installation is completed, all components can be retrieved in the folder  
*C:\Program Files\Microsoft Visual Studio\18\Community*

## 5.2 Use of alternative compiler

In order to enable the alternative C-compiler, you need to modify the automatically generated batch file **WESTStart.bat** located in the folder  
 ...\\Public\\Documents\\DHI\\WEST\\2026\\bin.

Instructions	Screen
Right click on <b>WESTStart.bat</b> and <b>Edit</b>	
Add the following statement as first line: <b>CALL " C:\\Program Files\\Microsoft Visual Studio\\18\\Community\\VC\\Auxiliary\\Build\\vcvars64.bat"</b> Mind the use of " " quotes. <i>Note: The path to vcvars64.bat file may differ depending on the version of Visual Studio installed (in this case, it refers to 2026 version)</i>	<pre data-bbox="763 990 1441 1358"> CALL " C:\\Program Files\\Microsoft Visual Studio\\18\\Community\\VC\\Auxiliary\\Build\\vcvars64.bat" SET INCLUDE=%INCLUDE%;C:\\Program Files (x86)\\DHI\\WEST\\2026\\include SET LIB=%LIB%;C:\\Program Files (x86)\\DHI\\WEST\\2026\\lib\\win64- msvc;C:\\Program Files (x86)\\DHI\\WEST\\2026\\third_party\\zig\\lib SET PATH=C:\\Program Files (x86)\\DHI\\WEST\\2026\\bin\\x64;C:\\Program Files (x86)\\DHI\\WEST\\2026\\bin;C:\\Program Files (x86)\\DHI\\WEST\\2026\\third_party\\zig;C:\\Program Files (x86)\\DHI\\WEST\\2026\\third_party\\clang-cpp\\bin;C:\\Program Files (x86)\\DHI\\WEST\\2026\\third_party\\omc\\bin;%PATH% SET TORNADO_CC_PLATFORM=zig SET TORNADO_CC_PATH= SET TORNADO_DATA_PATH=C:\\Users\\Public\\Documents\\DHI\\WEST\\2026 SET TORNADO_ROOT_PATH=C:\\Program Files (x86)\\DHI\\WEST\\2026 SET OPENMODELICAHOME=C:\\Program Files (x86)\\DHI\\WEST\\2026\\third_party\\omc START DHI.WEST.exe %* </pre>
In SET <b>TORNADO_CC_PLATFORM</b> , replace <b>zig</b> by <b>win64-msvc</b>	<pre data-bbox="763 1455 1441 1805"> CALL "C:\\Program Files (x86)\\Microsoft Visual Studio\\2022\\Community\\VC\\Auxiliary\\Build\\vcvars64.bat" SET INCLUDE=%INCLUDE%;C:\\Program Files (x86)\\DHI\\WEST\\2026\\include SET LIB=%LIB%;C:\\Program Files (x86)\\DHI\\WEST\\2026\\lib\\win64- msvc;C:\\Program Files (x86)\\DHI\\WEST\\2026\\third_party\\zig\\lib SET PATH=C:\\Program Files (x86)\\DHI\\WEST\\2026\\bin\\x64;C:\\Program Files (x86)\\DHI\\WEST\\2026\\bin;C:\\Program Files (x86)\\DHI\\WEST\\2026\\third_party\\zig;C:\\Program Files (x86)\\DHI\\WEST\\2026\\third_party\\clang-cpp\\bin;C:\\Program Files (x86)\\DHI\\WEST\\2026\\third_party\\omc\\bin;%PATH% SET TORNADO_CC_PLATFORM=win64-msvc SET TORNADO_CC_PATH= SET TORNADO_DATA_PATH=C:\\Users\\Public\\Documents\\DHI\\WEST\\2026 SET TORNADO_ROOT_PATH=C:\\Program Files (x86)\\DHI\\WEST\\2026 SET OPENMODELICAHOME=C:\\Program Files (x86)\\DHI\\WEST\\2026\\third_party\\omc START DHI.WEST.exe %* </pre>

<p>Optionally, if faster compilation at the expense of slower simulation is desired, add the following to WESTStart.bat:</p> <pre><b>SET</b> <b>TORNADO_CC_OPTIMIZE=no</b></pre>	<pre>CALL "C:\Program Files (x86)\Microsoft Visual Studio\2022\Community\VC\Auxiliary\Build\vcvars64.bat" SET INCLUDE=%INCLUDE%;C:\Program Files (x86)\DHI\WEST\2026\include SET LIB=%LIB%;C:\Program Files (x86)\DHI\WEST\2026\lib\win64-msvc;C:\Program Files (x86)\DHI\WEST\2026\third_party\zig\lib SET PATH=C:\Program Files (x86)\DHI\WEST\2026\bin\x64;C:\Program Files (x86)\DHI\WEST\2026\third_party\Program Files (x86)\DHI\WEST\2026\third_party\zig;C:\Program Files (x86)\DHI\WEST\2026\third_party\clang-cpp\bin;C:\Program Files (x86)\DHI\WEST\2026\third_party\omc\bin;%PATH% SET TORNADO_CC_PLATFORM=win64-msvc SET TORNADO_CC_PATH= <b>SET TORNADO_CC_OPTIMIZE=no</b> SET TORNADO_DATA_PATH=C:\Users\Public\Documents\DHI\WEST\2026 SET TORNADO_ROOT_PATH=C:\Program Files (x86)\DHI\WEST\2026 SET OPENMODELICAHOME=C:\Program Files (x86)\DHI\WEST\2026\third_party\omc START DHI.WEST.exe %* EXIT</pre>
<p><b>Save</b> WESTStart.bat and launch WEST</p>	