



MIKE SHE

Fully Integrated Exercises

Step-by-step training guide



DHI headquarters

Agern Allé 5
DK-2970 Hørsholm
Denmark

+45 4516 9200 Telephone

+45 4516 9333 Support

+45 4516 9292 Telefax

mike@dhigroup.com

www.mikepoweredbydhi.com

CONTENTS

MIKE SHE Fully Integrated Exercises Step-by-step training guide

1	Introduction.....	1
1.1	The MIKE SHE user interface.....	2
2	Getting Started Exercise.....	5
2.1	Start MIKE SHE	5
2.2	The MIKE Zero project.....	6
3	Setting up a MIKE SHE Flow Model	13
3.1	Create a new MIKE SHE setup.....	13
3.2	Set up the map overlays	15
3.3	Set up the simulation.....	18
3.4	Set up the model domain	23
3.5	Set up the topography.....	27
3.6	Define climate	30
3.7	Add land use	33
3.8	Add the river module	36
3.9	Specify the overland flow parameters.....	36
3.10	Build the unsaturated zone model	37
3.11	Build the saturated zone model	40
3.12	Specify output options and calibration targets	47
4	Running and evaluating MIKE SHE Flow Model.....	53
4.1	Pre-process the data.....	53
4.2	Run the simulation	57
4.3	View the results.....	58
4.4	View simulation statistics	67
4.5	Check the water balance.....	69
5	Building a MIKE HYDRO Model for MIKE SHE.....	77
5.1	Open the MIKE HYDRO model setup file	77
5.2	Explore the branch network and add a branch	79
5.3	View and add cross-sections from a DEM	83
5.4	Add boundary conditions.....	88
5.5	MIKE HYDRO – MIKE SHE coupling.....	88
5.6	Run a simulation	89
5.7	View the results.....	90
5.8	Add a weir structure	92
5.9	Re-run the model	94

6	Application Example: Impact of Groundwater Pumping	97
6.1	Set up a new base case scenario	97
6.2	Create a pumping scenario	101
6.3	Add the groundwater abstraction	102
6.4	Run the pumping simulation	104
6.5	Analyze the change in stream flow	105
6.6	Analyze the well drawdown.....	112
6.7	Analyze the change in water balance	120

Notes:

- The exercises assume that you have already installed MIKE SHE, and it is correctly licensed (Demo or a Full License).
- These step-by-step exercises are designed to illustrate the basic functionality available in the user interface and the basic steps required for integrated groundwater-surface water modelling.
- Although these exercises are based on real case studies, they have been significantly simplified to make the models run quickly. Thus, the parameter values may not be representative of real world values. Therefore, the exercises are not intended to illustrate best practices in integrated modelling.
- Although the entire exercises will not run in the demo mode, the exercises can be easily modified so that they will run in the demo mode by reducing the number of nodes or the simulation length. The necessary changes are noted in the exercises.
- As you do the exercises, you should initially take some time to look at the figures on each page before reading the text. This should help you understand the exercise instructions.

1 Introduction

In the hydrological cycle, water evaporates from the oceans, lakes and rivers, from the soil and is transpired by plants. This water vapour is transported in the atmosphere and falls back to the earth as rain and snow. It infiltrates to the groundwater and discharges to streams and rivers as base flow. It also runs off directly to streams and rivers that flow back to the ocean. The hydrologic cycle is a closed loop and our interventions do not remove water; rather they affect the movement and transfer of water within the hydrologic cycle.

MIKE SHE is an advanced, flexible framework for hydrologic modelling. It includes a full suite of pre- and post-processing tools, plus a flexible mix of advanced and simple solution techniques for each of the hydrologic processes. MIKE SHE covers the major processes in the hydrologic cycle and includes process models for evapotranspiration, overland flow, unsaturated flow, groundwater flow, and channel flow and their interactions. Each of these processes can be represented at different levels of spatial distribution and complexity, according to the goals of the modelling study, the availability of field data and the modeller's choices. The MIKE SHE user interface allows the user to intuitively build the model description based on the user's conceptual model of the watershed. The model data is specified in a variety of formats independent of the model domain and grid, including native GIS formats. At run time, the spatial data is mapped onto the numerical grid, which makes it easy to change the spatial discretisation.

MIKE SHE uses MIKE HYDRO river to simulate channel flow. MIKE HYDRO includes comprehensive facilities for modelling complex channel networks, lakes and reservoirs, and river structures, such as gates, sluices, and weirs. In many highly managed river systems, accurate representation of the river structures and their operation rules is essential. In a similar manner, MIKE SHE is also linked to the MOUSE sewer model, which can be used to simulate the interaction between urban storm water and sanitary sewer net-works and groundwater. MIKE SHE is applicable at spatial scales ranging from a single soil profile, for evaluating crop water requirements, to large regions including several river catchments, such as the 80,000 km² Senegal Basin. MIKE SHE has proven valuable in hundreds of research and consultancy projects covering a wide range of climatological and hydrological regimes.


The need for fully integrated surface and groundwater models, like MIKE SHE, has been highlighted by several independent studies. These studies show that few codes exist that have been designed and developed to fully integrate surface water and groundwater. Further, few of these have been applied outside of the academic community.

MIKE SHE has been used in a broad range of applications. It is being used operationally in many countries around the world by organisations ranging from universities and research centres to consulting engineers companies. MIKE SHE has been used for the analysis, planning and management of a wide range of water resources and environmental and ecological problems related to surface water and groundwater, such as:

- River basin management and planning
- Water supply design, management and optimisation
- Irrigation and drainage
- Soil and water management
- Surface water impact from groundwater withdrawal
- Conjunctive use of groundwater and surface water

- Wetland management and restoration
- Ecological evaluations
- Groundwater management
- Environmental impact assessments
- Aquifer vulnerability mapping
- Contamination from waste disposal
- Surface water and groundwater quality remediation
- Floodplain studies
- Impact of land use and climate change
- Impact of agriculture (irrigation, drainage, nutrients and pesticides, etc.)

1.1 The MIKE SHE user interface



MIKE SHE's user interface can be characterised by the need to

- Develop a GUI that promotes a logical and intuitive workflow, which is why it includes
 - A dynamic navigation tree that depends on simple and logical choices
 - A conceptual model approach that is translated at run-time into the mathematical model
 - Object oriented "thinking" (geo-objects with attached properties)
 - Full, context-sensitive, on-line help
 - Customised input/output units to support local needs
- Strengthen the calibration and result analysis processes, which is why it includes
 - Default HTML outputs (calibration hydrographs, goodness of fit, water balances, etc.)
 - User-defined HTML outputs
 - A Result Viewer that integrates 1D, 2D and 3D data for viewing and animation
 - Water balance, auto-calibration and parameter estimation tools.

- Develop a flexible, unstructured GUI suitable for different modelling approaches, which is why it includes
 - Flexible data format (gridded data, .shp files, etc.) that is easy to update for new data formats
 - Flexible time series module for manipulating time-varying data
 - Flexible engine structure that can be easily updated with new numerical engines

The result is a GUI that is flexible enough for the most complex applications imaginable, yet remains easy-to-use for simple applications.

In addition to the MIKE ZERO Project Explorer, the MIKE SHE document consists of 4 parts:

- Along the top - the **Tool bar** and drop-down **Menus**
- On the left - the dynamic **Data tree** and tab control
- In the middle - the context sensitive **Dialog area**
- On the right - the **Project Explorer**
- Along the bottom - the **Validation area** and **Mouse-over data area**

Tool bar - contains icon short cuts for many MIKE SHE operations that can be accessed via the Menus. The Tool bar changes depending on the tools that are currently in use.

Data tree - displays the data items required to run the model as it is currently defined. If you add or subtract hydrologic processes or change numeric engines, the make-up of the data tree will change.

Dialog area - is different for each item in the data tree.

Validation area - displays information on missing data or invalid data items. Any items displayed here are hot linked to the Dialog in which the error has occurred.

Mouse-over area - displays dynamic coordinate and value information related to the mouse position in the map area of any of the spatial Dialogs.

Project Explorer - displays the list of files that are in the current project. This is only active if the model is opened and edited via a Project File. Otherwise the section is blank.

2 Getting Started Exercise

Objective

Learn how to create a MIKE Zero Project and the associated project documents. Save the **MIKE SHE Examples Project** locally for use in the exercises.


2.1 Start MIKE SHE

2.1.1 Launch MIKE Zero

- from the Program menu select MIKE Zero:



The Program Files menu looks different depending on your operating system and your settings.



MIKE SHE is part of the MIKE Zero suite of modelling tools, which is a global DHI user interface for managing and manipulating data files and projects for many of the MIKE Powered by DHI software products. Thus, when you launch MIKE SHE, you are really launching MIKE Zero. MIKE Zero then provides the framework from which you can run MIKE SHE or any other product in the MIKE Zero family.

Also notice in the Start Menu icons for

MIKE SDK – this is set of programming functions and documentation that allows you to manipulate MIKE by DHI input and output files programmatically.

DHI License Administration – this launches a tool for managing your software licenses

MIKE View – This is a tool for evaluating the results of MIKE HYDRO River

Documentation – This links to a directory of all the installed documentation files

Release notes – Here you can find the latest information on the service packs that have been installed

MIKE to Google Earth – This tool allows you to map your results onto Google Earth

2.2 The MIKE Zero project


MIKE Zero is more than a set of modelling tools. MIKE Zero is a project management interface, with a full range of tools for helping you with your modelling project.

2.2.1 The MIKE Zero project window

The MIKE Zero Start Page includes two parts:

1. **The Project Overview table** lists the projects that you have recently accessed, along with their creation and last modified dates.
2. **The Project Explorer** is a view into the directory with all the files that are associated with the project.

The MIKE Zero project structure is designed to help you keep control of your project. By default it appears on the right hand side of the MIKE ZERO interface.



2.2.2 Install the MIKE Zero examples




The versions in the Program Files directory are read-only and provide you with an uncorrupted version of the example files. The **Install Examples** button copies all of the example files from the installation directory into your chosen directory for use in these exercises. If you want to start over, then you can simply re-install the examples.

- Click on the **[Install Examples...]** button and then select to install all of the MIKE SHE example files
- Select your Destination Directory to be the **Documents/MIKE Zero Projects** directory

Now you have a local duplicate copy of the **Examples Project** for use in these exercises.


For all of these exercises, please use the versions found in the Documents directory you just created.



2.2.3 Open the default examples project

After you have started MIKE Zero navigate to the default location of the installed MIKE SHE Examples Project.


- Select the **Open Project** button below the project list.
- Browse to the folder: **\Documents\MIKE Zero Projects\MIKE_SHE**
- Then open the existing project: **MIKE SHE exercises.mzp**



The files contained within the MIKE SHE Examples project will now appear in the Project Explorer



The Project Explorer may be hidden on the right side of the MIKE Zero window. If so, drag your mouse over to the Project Explorer tab, and the Project Explorer will appear. For this exercise, it is probably useful to lock the Project Explorer in place. This is done by clicking on the little thumbtack icon in the upper right hand corner of the Project Explorer. You are welcome to hide or unhide the Project Explorer at any time during the exercise.





If you have opened this project before, the project will be displayed in the list box. In this case, open by clicking on the project name.


Note: The Project Explorer may open with all the directories expanded out. So, you might like to close up some of the directories in the Project Explorer by clicking on the little icons.

2.2.4 MIKE Zero Features

Some features of the MIKE Zero main dialog are worth knowing about.


Toolbar

New files can be created and existing files opened from the New, , and Open, ,

icons. There is a Save, , icon that is active when you have a file open. However, MIKE SHE automatically saves your model whenever you Pre-process the data or Run a simulation.

Various other toolbars will be visible and active, depending on which files are open and the context of your cursor.

File menu



Under the File menu, there are some useful functions related to the overall setup of MIKE Zero.

Edit Unit Base Groups – this dialog allows you to change the default units associated with any parameter in MIKE SHE. The list of parameters is very long because it includes all parameters for all the MIKE Zero models by default.

- **Note on working with Imperial units** – By default, MIKE SHE works in SI units. In this dialog, you can load a template for US units. This will change all of the displayed units in the MIKE SHE dialogs to Imperial US units. However, be aware that MIKE SHE still works internally in SI. Thus, the log files etc are still written in SI units.

Edit Map Projections – this dialog allows you to add new map projections or edit existing map projects. The list is quite comprehensive, but your GIS organization may have special requirements.

User Settings – this dialog contains some useful setting, in particular, it allows you to change the default directory for new models etc. For example, if you always work on a shared network drive, you may want to change the default.


Project Properties – if you are using MIKE Zero Projects, then you may want to change, for example, the default location for your results.

2.2.5 Getting help


If you are using this exercise in a course, you are welcome to ask your instructor at any time for help.

However, if you are working on your own, there is an extensive on-line help.


- **On-line Help** - The full Help can be accessed from the top **Help...** menu. For MIKE SHE, this is the same as the full printed manuals.



- **F1 Context Help** - From within the Dialogs, context sensitive help is available by pressing the F1 key. This takes you to a specific help page for the dialog that you are currently viewing in the user interface.



- **Reference Manuals** - The full documentation in PDF format can be accessed from the Start Menu (Windows 7) or under the Apps in Windows 10.



2.2.6 Technical Support

Not all answers can be found in the documentation and help pages. In these cases, we are always available to answer questions via our Support Desk at mike@dhigroup.com.

You are also welcome to join our on-line user community at <http://forum.mikepoweredbydhi.com/>. Here you can post questions and learn from other users.

End of Getting Started Exercise.

3 Setting up a MIKE SHE Flow Model

The purpose of this exercise is to set up an integrated MIKE SHE model using predefined inputs. Through the exercise, basic MIKE SHE operations are practised and you will become familiar with various model tools for result processing.

The exercise is divided into two parts.

This Section covers the following topics:

- Creating a model
- Setting up the model domain and grid
- Adding the topography
- Specifying climate and land use
- Setting up the various modules: overland, unsaturated and saturated flow; and
- Controlling the outputs.

The second part, Section 4, covers

- Running the model, and
- Using some of the post-processing tools to evaluate the results

The models in these exercises are based on the Karup River catchment in western Denmark.


3.1 Create a new MIKE SHE setup

In the following steps you will be creating and building a new MIKE SHE model of the catchment based largely on pre-existing data files.




Ensure that you have installed the Example files in the previous Getting Started exercise, and have opened the **MIKE SHE exercises.mzp** project file in the My Documents folder.

3.1.1 Create a new MIKE SHE document

A MIKE Zero project is a collection of documents. All of the MIKE Powered by DHI documents can be created from the **File\New\File...** menu in the top pull-down menu or by clicking on the New File icon, , in the toolbar.

When the New File Dialog appears,

- select MIKE SHE on the left hand side,
- select Flow Model (.she) on the right hand side,
- click OK.



The default MIKE SHE Setup Dialog will now appear and the new .she file will be added to the project under the Model directory.



The **.SHE** file contains all the user-specified information required to run MIKE SHE. However, the file does not contain the actual time series and grid data. MIKE SHE only stores the path names to the other data files for time-series data and grid data. This greatly improves the flexibility of the user interface for keeping your model up-to-date with new data and for running calibration and prediction scenarios





You can use the same New document dialog to select any of the listed file types on the right hand side, or even navigate to one of the other items on the left hand side. For example, you may need to create a water balance (.wbl) file during calibration, or a new dfs0 time series file, which you will find under the MIKE Zero list.

3.1.2 Save the document file

The document file that you just created – in this case the .she document – is unnamed until you save it.

To save the file:

- **First**. Click on the **Karup_Basic** directory in the Project Explorer (this becomes the default location for the file to be saved to and ensures that the .she file is located correctly within the project folder structure)
- **Then**, use the File\Save menu item, or the Save icon 
- In the Save Dialog type in a file name (e.g. MyFirstMSHE – the .she extension will be added automatically)
- Click OK



3.2 Set up the map overlays

In many projects, the first thing you may want to do is to define the maps and overlays that you are going to use in your project.

MIKE SHE allows you to add graphical overlays using bitmaps, ArcView .shp files, etc. These overlays will appear on all maps shown in the graphical view in the user interface.

3.2.1 Set the display area

The basic display area of the model map view is defined in the top item of the data tree Dialog under *Display*:

- Use your mouse pointer to select *Display*




The Display item is located at the top of the data tree to make it easy to add and edit your background maps. In the Display item, you can add any number of images to your model setup, in a variety of formats. The images are carried over to the various editors, so you can keep a consistent display between the set up editor and, for example, the Grid Editor and the Results Viewer.

The option 'Default map display based on the Model Domain' means that the map view will be defined by the size of the model domain that you select in the next section of this exercise.

However, in some cases you may want the displayed map area should be much larger than the model domain, in which case you can define the map extents in this Dialog.

You can also import the extents from a shape or dfs2 file.

- In this case set the display area manually. The Karup model is set up in UTM_32N coordinates
- Lower Left corner: (Xmin, Ymin)=(493900, 6220750)
- Upper Right corner: (Xmax, Ymax)=(526400, 6255750)



3.2.2 Add an image map overlay

In the *Foreground* Dialog under *Display*:


- Click on the Add Item icon



Notice that a plus sign (+) appears beside the *Foreground* item in the data tree. This indicates that sub-items have been added in the data tree.


The Background and Foreground options refer to the way the overlays are displayed relative to the input data specified in the other Dialogs. Typically, you only need the Foreground display active.

Also, if you have multiple overlays, the order that they are listed defines the order in which they are displayed. Thus, you don't usually want a bitmap at the top of the list, since it would hide all of the lower overlays.



3.2.3 Define the file and geo-reference the bitmap

Now click on the plus sign beside the *Foreground* item in the data tree to expand the data tree. Then click on the sub-item to display the sub-Dialog.



The screenshot shows the 'Image Overlay' dialog box. It has a 'Display' checkbox which is checked. Below it is the 'Image File' field containing the path: '\\MIKE Zero Projects\\MIKE_SHE\\Karup_Basic\\Model Inputs\\GIS Data\\D200_2015.bmp'. There is a browse button (three dots) to the right of the file path. Below the file path is the 'Area Coordinates' section, which contains two rows of input fields: 'Min coords' and 'Max coords'. Each row has two columns: 'x:' and 'y:'. The 'Min coords' row has values 484404 and 6219450, both followed by '[m]'. The 'Max coords' row has values 533948 and 6257180, both followed by '[m]'. To the right of these fields is a button labeled 'Import geo reference from file...'. At the bottom is the 'Image Styles' section, which contains a 'Display style' dropdown menu set to 'Blend colors' and a 'Transparent color' dropdown menu.

In the sub-Dialog:

- click on the browse button, , and find the file **.\\Karup_Basic\\Model Inputs\\GIS Data\\D200_2015.bmp**



Since a bitmap image does not contain any geographical information (it is simply a list of pixel locations and colours), the bitmap must be oriented in space. To do so, you can either import the georeferenced coordinates from a world file or provide MIKE SHE with the coordinates of the lower left and upper right corners of the bitmap.

- Type in the coordinates as shown in the figure above
- Click on *Display* to make the map visible
- Set the *Display* style as *Blend Colors*, which will blend the map colours with any other displayed colours. This will prevent the bitmap from hiding the model data.


3.3 Set up the simulation

MIKE SHE includes several simulation modules. The navigation tree in the user interface depends on your choice of simulation modules.

3.3.1 Select simulation modules

In the *Simulation Specification* Dialog, make sure that all the the Water Movement items are checked On. Make sure that;

- Rivers and Lakes are on;
- *Finite Difference* is selected for the OL and SZ engines, and
- the *Richards equation* is selected for the UZ engine.



The Simulation Specification Dialog allows you to select, which flow components to include in your simulation. For example, if you want to include only the river and the exchange to the saturated zone, then you only need to select *Rivers and Lakes* plus *Saturated Flow*.

Not selecting some of the items can be a useful option during the initial model setup stage when you are setting up and calibrating a complex model.

In this dialog, you chose the numeric engine for the different hydrologic processes.


- There are three numeric engine options for the unsaturated zone and two each for both the Overland flow and Saturated Flow.
- The calculation method for the Evapotranspiration is automatically selected depending on the Unsaturated Flow option selected.
- The channel flow numerical method is selected in the MIKE HYDRO Setup.

3.3.2 Specify the simulation period

In the *Simulation period* Dialog:

- Specify the *Start date* and *End date*
 - Start Date: 1 January 2003
 - End Date: 31 December 2007

In this Dialog, you can either type in the dates or select the dates from a drop down calendar.




Demo Note: If you are using a Demo version, then the maximum length of simulation is 30 days. In this case you should use a shorter Simulation Period. For example, only the month of January 2003

If your simulation runs too slowly, then you can reduce the length of the simulation period without affecting the learning objectives.



Specification of the simulation period at this early stage in the model development is not a requirement. However, it is convenient because the time-varying input data you specify later is validated against the simulation period. Thus, when you specify a rainfall time-series file, a check is made to make sure that the time-series covers the simulation period.


In most cases, MIKE SHE is run as a transient model. If the model is run in steady-state, then the steady-state solution also follows this simulation period, by generating a series of identical steady-state solutions for each specified time step.

Typically, you will start the simulation from a Hot start condition. But, in this exercise we will start it from the defined initial conditions. The Hot-start allows you to start the simulation from the end of a previous simulation. You will often create a 'run-in' simulation that allows the model to dynamically equilibrate. Then, start the actual simulation at, for example, the end of a dry season.

3.3.3 Define time step parameters

In the *Time step control* dialog specify:

- *Initial time step* = 2 hrs
- *Max allow OL time step* = 0.25 hrs
- *Max allow UZ time step* = 2 hrs
- *Max allow SZ time step* = 2 hrs



The screenshot shows the 'MIKE SHE Flow Model Description' dialog box. On the left is a tree view with various model components. The 'Time step control' option is selected and highlighted in blue. On the right, the 'Time step control' tab is active, displaying several input fields:

- Time Steps:**
 - Initial time step: 2 [hrs]
 - Max allowed OL time step: 2 [hrs]
 - Max allowed UZ time step: 2 [hrs]
 - Max allowed SZ time step: 6 [hrs]
- Increment of reduced time step length:**
 - Increment rate (0-1): 0.05
- Parameters for Precipitation-dependent time step control:**
 - Max precipitation depth per time step: 10 [mm]
 - Max infiltration amount per time step: 10 [mm]
 - Input precipitation rate requiring its own time step: 0.1 [mm/hr]

At the bottom of the dialog are three tabs: 'Setup Data', 'Processed Data', and 'Results'.



MIKE SHE uses different time-steps for the different hydrologic processes. Normally, the Overland flow time-step is the smallest and the Groundwater time-step the largest. The river time step is controlled in MIKE HYDRO.

The overland flow time step is quite small because it is highly dynamic. The overland time step has to be the same or larger than the MIKE Hydro Time step

Generally, the time steps are relatively small in this example because the system is quite sandy and highly dynamic. In a less dynamic simulation, you would normally make the SZ time step larger.



The *Max infiltration amount* and the *Max precipitation depth per time step* are used to improve the numeric stability of the solution when there is ponded water on the ground surface. If the maximum values are exceeded, then the time step will be automatically decreased until this limit is reached.

3.3.4 Simulation control

We will use the default values for all the solver parameters. Details on these parameters can be found in the on-line Help.

Overland flow

You should use the default parameters for OL, but change to the Explicit solver. Leave the Manning equation for calculating overland flow into the rivers.



If you want to calculate flooding, then the explicit solver is required. However, the time step constraints on the explicit solver are more restrictive.

OL Computational Control Parameters

Solver Type and Solver-specific Parameters

☐ Successive Overrelaxation (SOR)

Maximum number of iterations:

Maximum head change per iteration: [m]

Maximum residual error: [m/d]

Under-relaxation factor: [0.01 - 1.0]

☒ Explicit (Recommended when overbank spilling is allowed)

Maximum courant number: [0.1 - 0.9] (for adaptive time step)

☐ Sub-divide overland flow cells for multi-cell OL method

Coarse cell sub-division

Common stability parameters

Threshold water depth for overland flow: [m]

Threshold gradient for applying low-gradient flow reduction:

Overland-River exchange calculation

☒ Manning equation (using OL flow Manning numbers)

☐ Weir formula: (Weir data specified in MIKE 11)

Threshold head difference for applying low-gradient flow reduction:

Unsaturated flow

We will use the default UZ solver parameters.

MIKE SHE Flow Model Description

- ☐ Display
- ☐ Simulation specification
 - ☐ Simulation title
 - ☒ Simulation period
 - ☒ Time step control
 - ☒ OL Computational Control Paramet...
 - ☒ UZ Computational Control Paramet...
 - ☒ SZ Computational Control Paramet...
- ☒ Model Domain and Grid
 - ☒ Topography
 - ☒ Climate
 - ☒ Land Use
 - ☒ Rivers and Lakes
 - ☒ Overland Flow
 - ☒ Unsaturated Flow
 - ☒ Saturated Zone
 - ☒ Storing of results
 - ☐ Extra Parameters

Setup Data Processed Data Results

UZ Computational Control Parameters

UZ-SZ Coupling Control

Max. profile water balance error [m]

Richards equation parameters

Iteration Control

Maximum no. of iterations

Iteration stop criteria (fraction of Psi)

Timestep Reduction Control (UZ Restart)

Max. water balance error in one node (fraction)



Richard's equation for unsaturated flow may produce water balance errors if the time step is large and the control parameters are set too loosely. Increasing the iteration control parameters will however increase the runtime which may not be desirable.

Problems with the water balance are reported in the water movement run log file and should be checked at the end of every simulation. It is also advisable to run the water balance tool to make sure the model is performing correctly.

Saturated flow

You should use the default parameters for SZ including the default PCG Transient solver

The screenshot shows the 'MIKE SHE Flow Model Description' window. On the left is a tree view of the model setup, and on the right is the 'SZ Computational Control Parameters' panel.

MIKE SHE Flow Model Description (Left Panel):

- MIKE SHE Flow Model Description
 - Display
 - Simulation specification
 - Simulation title
 - Simulation period
 - Time step control
 - OL Computational Control Paramet...
 - UZ Computational Control Paramet...
 - SZ Computational Control Paramet...
 - Model Domain and Grid
 - Topography
 - Climate
 - Land Use
 - Rivers and Lakes
 - Overland Flow
 - Unsaturated Flow
 - Saturated Zone
 - Storing of results
 - Extra Parameters

SZ Computational Control Parameters (Right Panel):

Solver Type

- ☒ Preconditioned Conjugate Gradient, Transient
- ☐ Preconditioned Conjugate Gradient, Steady State
- ☐ Successive Overrelaxation Package (SOR)

Iteration Control

Maximum no. of iterations	50
Maximum head change per iteration	0.005 [m]
Maximum residual error [m/d]	0.0005

Sink de-activation in drying cells

Saturated thickness threshold	0.05 [m]
-------------------------------	----------

Advanced Settings

- ☒ Gradual drain-activation (Recommended)
- ☒ Horizontal Conductance averaging between iterations (Recommended)

Under-relaxation

- ☒ No under-relaxation (Recommended)
- ☐ Under-relaxation with dynamic calculation of factor
- ☐ Under-relaxation with constant factor (0.01-0.99): 0.99

Maximum exchange from river during one time step

Max. fraction of H-point volume	0.9
---------------------------------	-----

At the bottom of the window, there are tabs for 'Setup Data', 'Processed Data', and 'Results'.


3.4 Set up the model domain

The model domain and the surface topography are required for all MIKE SHE components.

The model domain defines the horizontal extent of the model area, as well as the horizontal discretisation used in the model for overland flow, unsaturated flow and saturated groundwater flow

3.4.1 Define the model domain

In the *Model Domain and Grid* Dialog:




- Choose *Catchment defined by Shape File*
- Using the Browse icon, select the file
.Model Inputs\GIS Data\catchment.shp
- Set the *Shape axis* units to “meter”.
- Set the grid dimensions to
 - Number of cells in the X direction, NX = 65
 - Number of cells in the Y direction, NY = 70
 - Cell size = 500m
 - Rotation = 0
 - Origin (X0, Y0) = 493900, 6220750

- Map Projection Type = ETRS_1989_UTM_Zone_32N

A list of previously used map projections will appear in the drop down menu when selecting Map Projection Type. To find and use the projection for the first time

- click <Browse...>
- go to: *OpenGISProjections/Coordinate Systems/Projected Coordinate Systems/UTM/Other GCS/ ETRS_1989_UTM_Zone_32N*
- Click OK



The Map Projection Type allows you to use any valid map projection. The only restriction is that whichever projection you chose, you must be consistent with respect to all other map inputs. You cannot mix, for example, maps from two different UTM zones.

The NON-UTM option implies local rectangular coordinates, without a map projection.


MIKE SHE automatically assigns values of 1 to the internal cells and values of 2 to the boundary cells.


When you preprocess the data, the preprocessor calculates the model domain based on the .shp file and defines the model domain as a dfs2-grid with integer values 1 (internal point), 2 (boundary point) and zero values for areas outside the model domain. The pre-processor assigns all of the model parameters based on the dfs2-grid that is calculated from the polygon that you have specified in this step.


If you wish to change the model domain, all you have to do is modify the .shp file and preprocess the data again. However, be aware that previously specified data must still cover the new polygon. If it does not, then either a warning will be issued (saying that some values were automatically interpolated) or an error will be issued (if it can't interpolate the data)


3.4.2 Add the .shp polygon to the overlays

Go back to the Display item, and the *Foreground* Dialog:

- Click on the Add Item icon, 
- Change the *Type* to *Shape*




- Now, go to the new *Shape:Unknown* data tree item, and
- Then click on the Browse icon, 
- In the Open file Dialog, find the file **.Model Inputs\GIS Data\catchment.shp**



3.4.3 Adjust the display parameters for the .shp file

In the *Shape: catchment_meter.shp* Dialog:

- Choose line-colour
- Increase the line thickness (e.g. 0.5 or 1 mm)



Add more layers if desired. Line themes for showing the stream (karup_georef.shp) and observations boreholes (obswwells.shp) are located in the same folder.

Now in all of your map Dialogs, such as the *Model Domain* and *Grid* Dialog, the model domain should appear as a polyline on top of the map.

3.5 Set up the topography

The surface topography is required for all MIKE SHE components. The model topography defines the upper bound of the groundwater model as well as the upper surface of the unsaturated zone model. It is also used as the flow surface for overland flow.

Globally, Digital Elevation Model (DEM) data is widely available. Free DEM data at 90m and 30m resolution is available from the NASA SRTM data. There are also commercial providers of higher resolution DEM data, including DHI.


For Denmark, DEM data at different resolutions (0.4m, 1.6m and 10m) are freely available from <http://download.kortforsyningen.dk>. Data is provided as raster grid data in ArcGIS or MapInfo format. For this model, the 10m-resolution DEM data was downloaded and resampled to 50m. The data was then converted to a point ArcGIS shapefile.

The resampling can be important. High resolution DEM data will be interpolated in MIKE SHE. However, the GUI may become very slow if it is continually interpolating high-resolution data.


3.5.1 Define surface topography

In the *Topography* Dialog:

- Choose Point/Line (.shp) for the Spatial Distribution
- Select the file
.\\Model Inputs\\GIS Data\\Topo-processed.shp
- If the map is covered by black dots, click off the 'Show shape raw data' checkbox.



- This will turn off the shape file data points.
- The default interpolation method is Inverse Distance. Change the interpolation method to **Bilinear**



Spatially distributed data, such as topography can be specified using:

- a Uniform value
- a Grid file (.dfs2),
- a Point/Line (.shp) ArcView or ArcGIS map, or
- an ASCII file with distributed xyz values (Point XYZ (.txt)).

If a .shp file or a xyz-file is used, MIKE SHE will interpolate the data to the mesh defined in the Model Domain and Grid menu.


Hint: you can always see the Z-value at the cursor position at the bottom of your Graphical View.

Point/Line - Interpolation method - You can choose between Bilinear, Triangular, Inverse Distance and Inverse Distance Squared interpolation methods by selecting from the Interpolation method combo box.

- The Inverse distance methods are good for scattered data.
- Bilinear Interpolation is a good method for interpolating from gridded data and the
- Triangular method is good for interpolating from digitised contour lines.
- You can use the Online Help to find out more information on the interpolation methods, by clicking F1. At the bottom of the Help page, are references to Related Items, which will take you to the detailed descriptions of the interpolation methods.

SURFER - If you want to use interpolation methods not available in MIKE SHE, then you can use a program such as SURFER by Golden Software. In SURFER, you can save the interpolated SURFER grid to an XYZ file, and use the bilinear method in MIKE SHE to reproduce the Surfer interpolation.

ArcGIS Grid – If you have gridded data from ArcGIS, then you can use the Grd2Mike Tool (New File\MIKE ZERO\MIKE Zero Toolbox\GIS) to convert an ArcGIS grid to a dfs2 file.



Other tips:

- The search radius should be sufficiently large to ensure that each grid gets a value. For this exercise 1000 m is sufficient. However, the minimum search radius is two times the cell size. Search radii below this will have no effect. In this data set, the data density is quite high, and changing the search radius will have no effect.
- In some cases, such as when the grid is very large or the number of data points is large, then the interpolation can be time consuming. This can be a problem, since the grid is re-interpolated every time you enter the Dialog, as well as during the pre-processing step. To make the model more efficient, you can save the interpolation to a dfs2 file for use directly. To do this, right click on the map view and select *save to dfs2 file*.
- After you have saved the dfs2 file, you can then use it instead of the .shp file. Note though, that the link to the original .shp data is not lost, but simply hidden from view. This allows you to return to the original data if you want to change the discretisation of the dfs2 file, for example, if you change the size and shape of the Model Domain and Grid.


- If you have high-resolution DEM data, often the most efficient process is to use ArcGIS to interpolate the DEM data to the grid resolution that you want to use. At the same time, ensure that the point values are located at the model nodes. This will limit the amount of re-interpolation in the GUI, and ensure that your model topography is exactly as you expect.


3.6 Define climate


3.6.1 Define precipitation rate and temporal distribution


The precipitation is the actual amount of measured rainfall:

- Go to *Climate* in the menu and select *Precipitation Rate*
- For now, choose *Uniform Spatial Distribution*, which means that the same precipitation rate will be used all over the model domain.
- Change the temporal distribution from constant to time varying.




- Click on the  button to open the file browser
- Scroll through the list and pick the file **Precipitation.dfs0**
- Keep the default *Item* "Precipitation station 1" and click OK



The file browser lists all of the files in your project that are the correct file type. The green check beside the file name indicates that the file contents match the data requirements – for example, the correct time period and units type. If you are in doubt, you can click on the  button which will show you the data requirements.

In this case, you are using spatially uniform recharge data. The precipitation file contains data from several rain gauges. The particular rain gauge to use is selected under the Item in the browse Dialog. In this case, you are using only the data from Precipitation station 1.



In this model we are using a uniform rainfall rate over the entire catchment. For small catchments this is reasonable. In large catchments this would not normally be correct. By selecting Station-based, we can define regions or Thiessen Polygons where different rain gauge data is used. If you have access to gridded rainfall data, for example from radar rainfall stations, then you can use fully distributed rainfall data as well.

Precipitation is specified the same way data is collected from rain gauges. It can be input as mean-step accumulated values (e.g. average rainfall per day in units of mm/day) or, as step accumulated values (e.g. measured rainfall in a tipping bucket rain gauge in units of mm since the last measurement).


Finally, your calibration will depend on the frequency of your rainfall data. Your model will react very differently if you have monthly rainfall averages versus hourly rainfall from a local gauge. If you update your rainfall frequency, you will normally have to recalibrate your model.

3.6.2 Add Reference Evapotranspiration

MIKE SHE calculates actual evapotranspiration based on the evapotranspiration rate, the vegetation properties, and the soil moisture.

In the *Reference Evapotranspiration* Dialog:

- Use *Uniform* spatial distribution
- Use *Time-varying (.dfs0)* Data Type
- Use the browse button to select the file
.Model Inputs\Time\PotentialEvap.dfs0




Reference evapotranspiration can be specified in the same manner as precipitation, that is as constant or time-varying values and as uniform or spatially distributed values. As you're using *Uniform* distribution type, this evapotranspiration rate will be used throughout the model domain.

Evapotranspiration and Precipitation are highly correlated. Reference evapotranspiration is a function of solar radiation (sunshine), wind speed, relative humidity, and air temperature. All of these factors are affected by rainfall. Thus, it is desirable, but not critical, to use Precipitation and Evapotranspiration from the same weather station and at the same recorded frequency.

3.7 Add land use

3.7.1 Define the vegetation distribution

- Under *Land use* select the *Vegetation* Dialog:
- Use *Station based* Spatial distribution
- Specify *Grid Codes (dfs2)* as the Data Type
- Use the browse button to select the file
.Model Inputs\MAPS\Landuse.dfs2





The map now displays your vegetation distribution. The map (dfs2 file) contains 4 different integer codes that define 4 different areas. You now need to define the vegetation types and growth function that are associated with the 4 different areas.

3.7.2 Define vegetation types for each vegetation area

Each of the 4 different vegetation areas in the vegetation map appears as a sub-item in the data tree.

- Select the *Grid code = 1* item
- Change the ID to *Grass*
- Set the Temporal Distribution to *Vegetation property file*

- Use the new items icon, , to add a line in the *Crop Development* table.
- On the line in the Crop Development table
 - Use the browse button to select the vegetation property file (database file):
.Model Inputs\MIKE_SHE_vege.ETV
 - **BEFORE closing the dialog,**
From the pull-down *Veg type* combo box pick *Grass1*




- Set the Start date to **1. Jan. 2000**

(The start date is set before the simulation start data to ensure a full coverage of the simulation period).

- Set the Recycling Mode to *Each Entry*

For the remaining three vegetation types, set the *Temporal Distribution* to *Constant* and use the following values for the remaining items:

- Grid code = 2: ID=Forest, LAI = 6, RD = 800 [mm]
- Grid code = 3: ID=Shrubs, LAI = 2, RD = 500 [mm]
- Grid code = 4: ID=Wetlands, LAI = 4, RD = 500 [mm]



The *Crop Development* table allows you to define flexible crop rotation schedules. The schedule is defined in the Vegetation database, and the *Recycling Mode* is used to define how the schedule is repeated during the simulation.

The recycling mode defines what happens when the crop rotation ends.

- If no recycling is defined, then the vegetation properties will revert to 0.
- *Each Entry* means that each line in the table is repeated until the next start date.
- *Entire scheme* means that the rotation table starts over again after the last entry.
- *Entries, then scheme* means that the lines are repeated to fill in any gaps, and then the entire scheme is repeated.

For example,

- If you have one crop per year, then you can set up a simple annual schedule in the Vegetation database. Then if you choose the *Each Entry* option, the crop schedule will start over again as soon as it is finished. This is what we have done here.
- If you have multiple different crops per year, or a fallow crop in alternating years, then you could set this up as multiple lines in the Crop Development Table, with two different vegetation types and schedules.

Note: The recycling does not account for leap years. So, if you have very long simulations that require precise crop rotation dates, then you may want to set up a 4 year cycle in the Vegetation database.


3.8 Add the river module

You will now add an existing MIKE Hydro river setup to the model. Setting up the river in MIKE Hydro is detailed as a separate exercise in Section 5.

3.8.1 Add the river module

In the Rivers and Lakes Dialog:


- Use the browse button to select the existing *.mhydro* file for the Karup catchment:
.Model Inputs\MIKE HYDRO\karup.mhydro



3.9 Specify the overland flow parameters

In the *Overland Flow* Dialog (in the MIKE SHE GUI), specify

- Manning's M equal to 2 [$\text{m}^{1/3}/\text{s}$]
- Detention storage equal to 4 [mm], and
- Initial water depth equal to 0 [m].



The Karup catchment is quite sandy, and in this simulation there are no serious storm events. Thus, in reality, overland flow is insignificant for this simulation.

You can disable overland flow by specifying a Manning's $M = 0$ [$\text{m}^{1/3}/\text{s}$]. Setting the Manning's M to zero locally is sometimes a useful way of speeding up the simulation by turning off the overland flow calculation in areas of permanently ponded water, such as small reservoirs. However, a Manning's M of zero will prevent any overland flow from entering the cell.

The Detention Storage defines the depth of ponding required before Overland Flow occurs. A high Detention Storage value will effectively turn off Overland Flow. Again, this is very useful when you want to locally turn off Overland Flow, for example in lakes or ponds.

You can play with the Overland flow parameters later, if you like.


3.10 Build the unsaturated zone model

The unsaturated zone model calculates recharge to the groundwater model and is closely linked to the actual evapotranspiration, as the roots remove water from the unsaturated zone. Soil physical properties are stored in a soil-database. The link between soil-type distribution maps and soils in the soil-database are established similarly to the link between vegetation-distribution maps and vegetation types.

3.10.1 Calculation column classification

In the *Unsaturated Flow* Dialog:

- Choose *Calculated in all grid points* (default) for the column classification type




You should avoid Automatic UZ column classification and always use *Calculated in all grid points*.


MIKE SHE allows you to lump similar UZ profiles together to reduce the computation time. In this case, the results of one column are copied to other similar columns. This option was very useful in the past when computers were slower. However, this should be avoided now. The option has been retained to support backwards compatibility and some special cases.

Demo Note: You must use the Automatic Classification if you are using the demo version. In the Demo mode, the model size is restricted to a maximum of 155 UZ computational cells.

3.10.2 Define the soil profile distribution map

In the *Soil Profile Definitions* Dialog:

- Use *Distributed* for the Spatial Distribution
- Use *Grid codes (dfs2)* distribution data type
- Use the browse button to select the dfs2 grid file
.Model Inputs\MAPS\soil.dfs2




The soil map contains three different code values, which now need to be associated with three soil profiles.

3.10.3 Define soil profiles (horizons)


Each of the 3 different soil areas in the soils map appears as a sub-item in the data tree. For each soil zone

- Select the line in the Data Tree (Grid code 2, etc)
- Set the Soil Profile depth to 41m
- Use the browse button to select the UZ soil-database file
.Model Inputs\UNSODA basic soil classes.uzs
- **BEFORE clicking OK**, select the soil type as follows:

Grid Code = 2	Silt Loam
Grid Code = 3	Loamy Sand
Grid Code = 4	Loam

- Rename the Profile ID
- Add 4 lines to the vertical discretization, using the add button 
- Set the vertical discretization as follows:

	From depth	To depth	Cell height	No of cells
1	0	3	0.25	12
2	3	5	0.5	4
3	5	13	1	8
4	13	41	2	14



MIKE SHE Flow Model Description

- Display
- Simulation specification
- Model Domain and Grid
- Topography
- Climate
- Land Use
- Rivers and Lakes
- Overland Flow
- Unsaturated Flow
 - Soil Profile Definitions
 - Silt Loam
 - Loamy Sand
 - Loam
- Saturated Zone
- Storing of results
- Extra Parameters

Setup Data Processed Data Results

UZ Soil Profile Definition

Profile ID: Silt Loam Grid code value: 2


Soil Profile:

	From depth	To depth	Soil name	UZ Soil property file
1	0	41	Silt Loam	C:\Users\...\Model Inputs\UNSODA basic soil cl

Vertical Discretization:

	From depth	To depth	Cell height	No of cells
1	0	3	0.25	12
2	3	5	0.5	4
3	5	13	1	8
4	13	41	2	14



To facilitate the process you can add four lines using the add button . Then select all the lines in the table (click in the upper right corner of the table). Then copy and paste the vertical discretization table into the other soil zones.


The UNSODA database is a list of standard soil types developed by the US Department of Agriculture.

3.10.4 DEMO MODE only: Define groundwater table for UZ classification

Demo Note: If you are using the Demo mode, then you must use the Automatic classification method, which requires you to specify a water table

The depth to the groundwater table is one of the criteria that are used when the automatic (lumped) unsaturated zone classification is used.

- In the *Unsaturated Flow* dialog change the *Classification Type* to 1: Automatic
- In the *Groundwater depths used for UZ classification* dialog specify *Use initial water table for classification*
- Define 3 depth classes 1, 5 and 10 meters



3.11 Build the saturated zone model


Before defining your computational layers you must input a geological model, which is defined as part of the saturated zone.

A geological model may be defined as a combination of layers and lenses. Once the geological model is defined you may choose computational layers that are either identical to the geological layers or you may choose different computational layers. If the computational layers differ from the geological layers MIKE SHE's pre-processor will transfer the hydraulic properties of the geological model to the computational mesh.

3.11.1 Specify the Saturated zone (groundwater) options

In the *Saturated Zone* dialog:

- Select *Include subsurface drainage*. This will ensure that any springs drain to the streams.
- There are no pumping wells for now, so make sure that the *Include pumping wells* is not selected.
- Select *Assign parameters via geological layers*





The geology data can be assigned using both geological layers and geological units. If you choose the geological layers approach then the hydraulic properties are assigned as spatially distributed within the layer. If you use gridded data or point data, the hydraulic properties are smoothly interpolated to the model grid.

If you chose the geological units approach, then you must specify a distribution of geological units for each geological layer, for example, by a polygon file. In this case, all of the model cells in each polygon are assigned a value for each of the hydraulic properties.

The geologic units method is often specified when you use the AUTOCAL program for parameter estimation and automatic calibration. In this case, the parameters for each polygon can be estimated automatically and the model sensitivity for each parameter calculated.




3.11.2 Define the number of geologic layers


In this exercise, we will only have one numerical layer.

In the *Geological Layers* dialog:

- Keep the existing default layer name *Aquifer*



By default there is already one layer in the model. Additional layers can be added by clicking on the *Add Item* icon, , deleted by clicking on the *Delete Item* icon, , or moved up and down by clicking on one of the *Move Item* icons, .




Each of the Geological layers includes one item in the data tree for each of the properties. Additional layers will add additional sets of items to the data tree.


Increasing the number of saturated zone model layers allows you to better represent vertical flow and exchange between geologic layers. A fine vertical discretisation may also be required for solute transport simulations.

MIKE SHE allows you to have any number of layers in the saturated zone. However, the more model layers you have, the higher the computational effort and the more memory is needed. If you need more layers, it is always better to start with a few layers and do the initial calibration. Then add layers as necessary, while ensuring that the model remains stable and computational effort remains reasonable.

3.11.3 Define layer bottom (lower level)

In the *Lower Level* Dialog for Aquifer:


- Select *Point/Line (.shp)* in the *Spatial Distribution* combo box
- Using the file browse button, , select the file **.Model Inputs\GIS Data\layer1.shp**
- Untick the 'Show shape raw data' checkbox
- Use the Bilinear interpolation method, and
- Use a Search Radius of 1000m



3.11.4 Assign hydraulic properties


The remaining hydraulic properties are listed under the Lower Level item. For each item:

- Select *Uniform* under the *Spatial distribution* combo box and specify the following values:
 - Horizontal hydraulic conductivity = 0.00026 [m/s]
 - Vertical Hydraulic Conductivity = 9.3e-5 [m/s]
 - Specific Yield = 0.2 [-]
 - Specific Storage = 0.0001 [1/m]



3.11.5 Define the subsurface drain reference system

- Under *Drainage*, choose *Drainage routed downhill based on grid codes*



Drainage routing can be a very complex process. Simply removing the water from the model is the simplest drainage option. However, in most situations, drainage actually discharges to the river system.

Groundwater Drainage is a very powerful feature of MIKE SHE.

- The simplest routing method for the drainage is to route it downhill based on the drain levels. The drainage will enter the river whenever it intersects a river link. However, this can lead to ponding in local depressions in flat terrains.
- More complicated is the second option *Drainage routing based on grid codes*, where the drainage is routed downhill but only from certain cells. However, if you specify a single Drain Code, then the drainage will be to the nearest river.
- *The Distributed drainage options* allow you to route drainage to specific MIKE HYDRO nodes or MIKE Urban sewer manholes.

3.11.6 Define groundwater drainage

In the *Drainage Level* Dialog:

- Select *Uniform* under *Spatial Distribution*
- Use the value : -0.5 [m] **(Note negative sign)**
- Check on “*Values relative to ground*”



The *Values relative to ground* tells MIKE SHE that you have drains located 0.5 meter below ground surface in the entire model domain. If the groundwater table is higher than the drainage level drain flow will be produced and routed to a receiving cell or river.

In the *Time Constant* Dialog:

- Select *Uniform* under *Spatial Distribution*
- Use the value = 5.6e-008 [1/s]

In the *Drain Codes* Dialog

- Select *Uniform* under *Spatial Distribution*
- Set the Grid Code value = 1



The drain time constant can be thought of as an empirical factor that accounts for the time it takes for the water to drain. For example, in the case of agricultural drains, the time constant could be affected by drain spacing, drain diameter, clogging, etc. In the case of natural drainage, the time constant is affected by the distribution of drainage ditches and channels.

A time constant closer to 1 implies that the water drains more quickly and the drain acts more like a constant head boundary, when the water table is above the drain level. Whereas, a value closer to 0 implies that the water drains more slowly. A value of 0 turns off the drainage.

An Extra Parameter option is available for time varying drainage parameters.


3.11.7 Define attributes of groundwater computational layers

The computational layers are defined independently of the geological layers. While the *Geological Layers* have geological attributes, the *Computational Layers* include computational attributes such as initial conditions and boundary conditions. The properties of the geological layers are mapped and interpolated to the computational layers during the model preprocessing.

Although, MIKE SHE allows you to define *Computational Layers* independent of your *Geological Layers*, in this exercise computational and geological layers will be identical.

In the *Computational Layers* Dialog:


- Select *Defined by geological layers* as the *Type of Numerical Vertical Discretization*
- Use *Minimum layer thickness* = 0.5 [m]




The Minimum layer thickness is used to keep layers from crossing or completely pinching out, which would cause numerical difficulties.

3.11.8 Define groundwater initial conditions

In the *Initial Potential Head* Dialog:

- Select *Grid file (.dfs2)* under *Spatial Distribution*
- Using the file browse button, , select the file **.Model Inputs\Maps\init-head-500.dfs2**



You are using an initial head from a previous model run, which gives you a good starting point. In a real model, you might initially start from a value such as 3 m below the

topography. However, such a value will require a “run in time”, as the model may take several months to equilibrate.



However, in most cases it is more effective to use a Hot Start. If you use a Hot Start, then the initial condition defined here is ignored.


An alternative is to run the model as a steady-state simulation and then use the steady-state solution as an initial condition. However, the steady state solution still might not be a reasonable starting point depending on how steady the groundwater table is. For example, the steady-state condition with pumping active might, in fact be nearly dry.

3.11.9 Define groundwater boundary conditions

The *Outer Boundary* is defined by the row of cells on the outside of the model domain. The outer boundary is defined by the *Model domain and grid* file, as all points with a code value of 2 (boundary point).

In the *Outer Boundary* Dialog:

- Press the *Add Item* Icon, 
- Select *Zero Flux* (default) as the boundary type
- Click on the *Add Point* icon, , and click anywhere on the map



Outer Boundary Conditions

Boundary segments specified clockwise:

Segment name	Type	From X coordinate	From Y coordinate	To X coordinate	To Y coordinate
1	Zero-Flux	515667.91	6244441.59	515667.91	6244441.59

[meter]

Outer Boundary Conditions


Boundary type

- Gradient
- Flux
- Fixed Head
- Zero-Flux
- Undefined boundary points
- Inner point
- Undefined Value

500000 510000 520000 [meter]



This now gives you a no-flow boundary condition along the entire outside of the model. If the entire outer boundary is a no flow boundary, then this step is actually unnecessary because by default the outer boundary is no flow.

The outside of the model can be divided into boundary sections, by clicking on the *Add Item* icon again. Then click on the *Add Point* icon, , again. Finally, click on the map

to define the location of the boundary point end point. The boundaries are specified clockwise around the model starting at the first point in the table.

The outer boundary conditions are defined independent of the model grid. Thus, if you change your model grid the boundaries will be interpolated automatically to the new grid based on the nearest boundary cells to the point locations. If you change the shape or extent of the grid, you should check that your boundaries have not moved unexpectedly.

Internal boundaries are used to specify such things as lakes and reservoirs that are not included in MIKE HYDRO River. In this case you could specify a constant head or a general head boundary for a lake.

Internal boundaries are distinguished from outer boundaries because on the outside of the model, you can specify flux and gradient boundaries.

3.12 Specify output options and calibration targets

In MIKE SHE, there are 3 primary outputs:

- **Detailed time series** – This is a point value of a MIKE SHE output at EVERY time step, for example, Depth of Ponding.
- **Gridded output** – This is a 2D or 3D grid of values of a MIKE SHE output at every STORED time step, for example groundwater head elevation.
- **Detailed river time series** – This is a point value of the water level or flow rate in the defined streams in the model.

Both Detailed Time Series Output types automatically generate an HTML plot of the value as the simulation progresses. It also allows simulated output to be compared to observed output and calculates a number of statistics for model error. The HTML plots can be copied directly into reports.


The Gridded output is stored less frequently to conserve space on your hard disk. Likewise, many gridded outputs are not saved by default. Gridded output is stored as dfs2 (2D grid time-series files) or dfs3 (3D grid time-series files). If output data is stored too frequently, you may get very large and unwieldy result files. Thus, before running the simulation you should consider what and how often you need to save the data

A time series can be created for any point in the model domain from the Gridded Output, but the frequency of the values will be the same as the Storing Timestep.

More detail on evaluating the output is in the next step-by-step Exercise.

3.12.1 Storing of results


- Click on Storing of Water balance data
- Set the Storing interval for grid series output to a daily frequency (24 hours) for Overland, Precipitation ET UZ, SZ-heads and SZ-fluxes.



The Water balance items are used during the post-processing of the results to calculate water exchanges between the various components

The Hot start data is used for starting simulation from a previous result. This is useful when the run-in time for the simulation is long. In this case, you can run the initial simulation for a year or two. Then start subsequent simulations from a more reasonable initial condition. A good rule of thumb is to use a hot start condition near the end of the dry season, when water levels are low and conditions are more stable.

3.12.2 Define detailed time series output items

- Select the *Detailed timeseries output*
- Use the Add item icon, , to add 4 items to the list
- For each item,
 - Set the name
 - Select *head elevation in saturated zone* under Data Type
 - Define the X, Y coordinates from the table below:



Name	X-coordinate	Y-coordinate
Obs 5	518003	6229169
Obs 35	507700	6238357
Obs 37	511408	6241637
Obs 65	502766	6246299


- Define the Depth = 5

To add the observation data, you need to

- Check on the *Incl. Obs. Data* checkbox
- For each observation point,

- Use the browse button to select the file
.Model Inputs\Time\HeadObservations.dfs0
- BEFORE clicking OK, you need to select the appropriate Item from the combo box. (e.g. Obs well 5 for the entry named Obs 5)



The X and Y location can be selected on the map using the  button. This is useful if you want to create a detailed output of specific output items at a critical locations.

You are also welcome to add any other points and data items you like.


The *New Plot* checkbox is used to define whether or not a new html plot is created during the simulation. For example, if you uncheck the first box, then the first two items will be plotted on the same graph.

3.12.3 Create a detailed time series for the MIKE HYDRO output

MIKE View is used to evaluate the output from MIKE HYDRO River. However, MIKE SHE allows you to create a detailed time series with observations during the simulation, similar to the other MIKE SHE outputs.

Add a detailed discharge time series to the end of the Karup River.

- Under *Storing of results* select *Detailed M11 timeseries output*
- Specify the name and location below:
 - **Name:** 20.05 (outlet)
 - **Data type:** Discharge
 - **Branch name:** Karup River
 - **Chainage:** 52000
 - **Incl Obs:** check
 - **File name:** `.\Model Inputs\Time\flow.dfs0`, and then select the item: 20.05



To add a Detailed MIKE HYDRO River time series, you have to know the chainage of the h-point (for Water Level) or the q-point (for Discharge) ahead of time. If the value is not exact, then MIKE SHE will look for the nearest point, within a certain search radius. If there is no nearby point, then the output will be ignored.

3.12.4 Select gridded outputs

In the *Grid series output* Dialog many items will already be selected if you have turned on the storing of Water Balance data.

- Some gridded items of interest are not connected to the water balance data. By clicking on the check box, turn on
 - 8. Actual evapotranspiration,
 - 30. Total Recharge to SZ, (negative)
 - 35. Water content in the unsaturated zone.and
 - 39. Depth to phreatic surface

MIKE SHE Flow Model Description

- ☐ Display
- ☐ Simulation specification
- ☒ Model Domain and Grid
- ☒ Topography
- ☒ Climate
- ☒ Land Use
- ☒ Rivers and Lakes
- ☒ Overland Flow
- ☒ Unsaturated Flow
- ☐ Saturated Zone
- ☒ Storing of results
 - ☒ Detailed timeseries output
 - ☒ Detailed M11 timeseries output
 - ☒ Grid series output
- ☐ Extra Parameters

Grid series output

	Enable	Item	Required for	Filename
1	<input checked="" type="checkbox"/>	precipitation rate	Water Balance	
2	<input type="checkbox"/>	average water content in the rootzone		
3	<input type="checkbox"/>	rooting depth		
4	<input type="checkbox"/>	leaf area index		
5	<input type="checkbox"/>	crop coefficient		
6	<input type="checkbox"/>	reference evapotranspiration		
7	<input type="checkbox"/>	ETref x Kc		
8	<input checked="" type="checkbox"/>	actual evapotranspiration		
9	<input checked="" type="checkbox"/>	actual transpiration	Water Balance	
10	<input checked="" type="checkbox"/>	actual soil evaporation	Water Balance	
11	<input checked="" type="checkbox"/>	actual evaporation from interception	Water Balance	
12	<input checked="" type="checkbox"/>	actual evaporation from ponded water	Water Balance	
13	<input checked="" type="checkbox"/>	canopy interception storage	Water Balance	
14	<input checked="" type="checkbox"/>	evapotranspiration from SZ	Water Balance	
15	<input checked="" type="checkbox"/>	depth of overland water	Water Balance	
16	<input checked="" type="checkbox"/>	overland flow in x-direction	Water Balance	
17	<input checked="" type="checkbox"/>	overland flow in y-direction	Water Balance	
18	<input type="checkbox"/>	flow from overland to river		
19	<input checked="" type="checkbox"/>	flooded (yes,no)	Water Balance	
20	<input checked="" type="checkbox"/>	flow from flooded areas to river	Water Balance	
21	<input checked="" type="checkbox"/>	Overland flow to MOUSE	Water Balance	
22	<input checked="" type="checkbox"/>	External sources to Overland (for OpenMI)	Water Balance	
23	<input type="checkbox"/>	overland water elevation		
24	<input type="checkbox"/>	Mean OL Wave Courant number (explicit OL)		
25	<input type="checkbox"/>	Max OL Wave Courant number (explicit OL)		
26	<input type="checkbox"/>	Max Outflow OL-OL per Cell Volume (explicit OL)		
27	<input checked="" type="checkbox"/>	infiltration to UZ (negative)	Water Balance	
28	<input checked="" type="checkbox"/>	exchange between UZ and SZ (pos.up)	Water Balance	
29	<input checked="" type="checkbox"/>	UZ deficit	Water Balance	
30	<input checked="" type="checkbox"/>	Total recharge to SZ (pos.down)		
31	<input type="checkbox"/>	rate of change in UZ storage		
32	<input type="checkbox"/>	epsilon calculated in UZ		
33	<input checked="" type="checkbox"/>	External sources to UZ columns (for OpenMI)	Water Balance	
34	<input type="checkbox"/>	unsaturated zone flow		
35	<input checked="" type="checkbox"/>	water content in unsaturated zone		
36	<input type="checkbox"/>	pressure head in unsaturated zone		
37	<input type="checkbox"/>	root water uptake		
38	<input type="checkbox"/>	External sources to UZ nodes (for OpenMI)		
39	<input checked="" type="checkbox"/>	depth to phreatic surface (negative)		
40	<input checked="" type="checkbox"/>	head elevation in saturated zone	Water Balance	
41	<input type="checkbox"/>	saturated thickness of SZ layer		
42	<input type="checkbox"/>	SZ horizontal conductivity (for DA-OpenMI)		
43	<input type="checkbox"/>	SZ vertical conductivity (for DA-OpenMI)		
44	<input checked="" type="checkbox"/>	seepage flow SZ -overland	Water Balance	
45	<input checked="" type="checkbox"/>	seepage flow overland - SZ (negative)	Water Balance	
46	<input checked="" type="checkbox"/>	External inflow to SZ drain (for OpenMI)	Water Balance	
47	<input type="checkbox"/>	seepage flow Deficit (FEFLOW coupling)		
48	<input checked="" type="checkbox"/>	groundwater flow in x-direction	Water Balance	
49	<input checked="" type="checkbox"/>	groundwater flow in y-direction	Water Balance	
50	<input checked="" type="checkbox"/>	groundwater flow in z-direction	Water Balance	
51	<input type="checkbox"/>	SZ head elevation stored with SZ flows		
52	<input checked="" type="checkbox"/>	groundwater extraction	Water Balance	
53	<input checked="" type="checkbox"/>	SZ exchange flow with river	Water Balance	
54	<input checked="" type="checkbox"/>	SZ drainage flow from point	Water Balance	
55	<input checked="" type="checkbox"/>	SZ flow to general head boundary	Water Balance	
56	<input checked="" type="checkbox"/>	SZ flow to MOUSE	Water Balance	
57	<input checked="" type="checkbox"/>	External sources to SZ (for OpenMI)	Water Balance	

Setup Data
Processed Data
Results


End of the Exercise

4 Running and evaluating MIKE SHE Flow Model

You can start this exercise by either loading a pre-defined MIKE SHE setup file, or using the model that you developed in the previous Chapter.

If you are starting the exercises here, then

- Use the Open icon to open the **Karup_basic.she** file



This model should be similar to the model you would have obtained by following the step-by-step instructions in the previous Chapter.

In this exercise, the MIKE SHE filename is defined as **YourFilename.she**, as it may differ from the one that you are using.


This exercise will familiarize you with the various output functions in MIKE SHE. However, the exercise will guide you through only the most basic functionality of the tools, including the Result Viewer, the Plot Composer, and the Water Balance tool


4.1 Pre-process the data

You have now specified all the input required for the model. Up to this point, all of the input data has been specified independently of the numerical model. You have specified only the characteristics of the numerical model that will be run.

Before actually running the model, you must run the *Pre-Processor*. The *Pre-Processor* extracts all of the spatial data that you have included and builds the actual model files.


4.1.1 Run the preprocessor

Click on the  icon to start the *Pre-Processor*.



The preprocessor will start the MIKE Zero Launch utility.

- Click OK



Upon successful completion of the Pre-processing, you should check the model pre-processor log file to ensure the pre-processing finished without any errors. If the Pre-processing did fail, then the log file should contain some information to help you locate the problem.

The Pre-processed log files are by default located in the Result folder under MIKE SHE exercises.


- Go to the results in **Result\YourFilename.she - Result Files** folder and double click on **YourFilename_PP_Print.log** (the file should open in Textpad)

Scroll to the bottom of the file and check that the last line to ensure that the Pre-processing was successful.

4.1.2 View the preprocessed data

After successfully running the *Preprocessor*,

- Click on the *Processed Data* Tab located at the bottom of the Navigation Tree.
- Then, click on the items in the data tree and explore the processed data.



The pre-processor creates a .fif file that contains the cell values etc. that will be used in the simulation. The processed data has been interpolated to the computational mesh, exactly as the simulation engine will read it. However, the .fif file is a binary format optimised for use by the numerical engine.

The .fif file embeds all geometric data. Temporal data (time-series data) are not contained in the .fif file, but are read directly from the source data files during the simulation.

To view the pre-processed data, a parallel set of .dfs2 and .dfs3 files are also created so that the standard MIKE Zero tools can be used to view the data.

It is the dfs data that is shown in the data tree and listed in the file name text box. Clicking on the View button opens the Grid Editor with the current pre-processed data file loaded – with all the current overlays.

Spend some time moving around in the *Processed Data* and make sure you understand the input data and the relation between *Setup Data* and *Processed Data*.



If you want to change any of the values in the Processed Data, you cannot just change the values in the Grid Editor. The values that you see are not the ones that will be used in the simulation. Therefore to change the values you have to:

- Edit the values in the Grid Editor,
- Save the parameter to a new dfs2 file, and
- Then edit the Setup tab parameter to read from the new dfs2 file that you created.


4.1.3 View the river link setup



The MIKE HYDRO network is interpolated to the cell boundaries of the model grid. The interpolated river locations are called river links.

In the *Processed Data Tab* the most recent pre-processed file is automatically loaded

- Go to the *River Links* Item in the data tree to view the pre-processed river links:
- View the location of the river links in the computational mesh.



A .shp file of the River Links is also automatically created during the pre-processing. This file can be loaded as a background map in MIKE SHE, or in any of the MIKE Zero display tools, such as the Grid Editor, Plot Composer, and Results Viewer.

4.1.4 View the river bank elevations vs topography



A mismatch between the topography and the bank elevations will sometimes lead to poor OL-River exchange. You can use this item to locate areas where bank elevations are poorly matched to the topography. Occasional, random areas of mismatch are OK.

In MIKE HYDRO, you specified cross-sections. Each of the cross-sections includes a left and right bank elevation. These elevations define how the river interacts with Overland flow.


- Overland flow will only flow into the river if the water level on the land surface is higher than the bank elevation (and higher than the river level).
- If overbank spilling is allowed (Default = off), the river will only spill on to the flood plain if the river water level is higher than the bank and higher than the topography.

If water ponds along the edge of your river, it will normally infiltrate and enter the river via baseflow.


A poor match in the elevation is sometimes a sign that your cross-sections are much wider than your cell size. Typically, the elevation rises away from the river, and if you define cross sections much wider than the river, then you risk having the bank elevations

defined many metres too high. A good rule of thumb is to define your cross-sections as the normal bank full level.


If your bank-full cross-sections are much wider than your cell size, or if you want to simulate large inundated areas, then you may want to use the Flood Code option.



4.2 Run the simulation

In the Toolbar, click on the Water Movement  icon to run the simulation. This will start the MIKE Zero Launch utility.


- Click OK





The Launch utility allows you to change the *CPU Priority* and the *Results Folder* prior to the start of your simulation.

You can also change the *CPU Priority* during the simulation by clicking on the yellow button in the lower right corner of the user interface. You can stop the simulation entirely by clicking on the red button.



4.3 View the results


Upon successful execution of the model you are now ready to view the results. First you should check the model run log files to ensure the model finished without any errors. The result files and log files are by default located in the Result folder under MIKE SHE exercises.

- Go to the results in **Result\YourFilename.she - Result Files folder** and double click on **YourFilename_WM_Print.log**
- Scroll to the bottom of the file and check whether the different model components converged. Note that maximum iterations for some of the components may have been exceeded. This could be an indication of mass balance errors and we will check this when we create the water balance.

4.3.1 Locate the detailed time series output results

After successfully running the model:

- Click on the *Results* Tab located at the bottom of the Navigation Tree and select **MIKE SHE Detailed Time Series**.



All of the observations should also be visible.


You can add additional detailed time series items now and re-run the model.



The *MIKE SHE Detailed Time Series* output Dialog, under *Simulation Results*, lists the Detailed Time Series results you have chosen to store during the MIKE SHE simulation.

If you have specified more than 5 items for detailed time series output, then you will only see a page of links on the main *Detailed time series* page. The links will direct you to separate .html files with 5 graphs in each.


To plot multiple items on a graph, you can use the New Plot column in the Setup to combine output in one graph. If you unclick the checkbox, then this item will be plotted on the same graph as the previous item.



	Name	Data type	New plot	X	Y	Depth		Incl. Obs. Data	
1	Obs 5	head elevation in saturated zone	<input checked="" type="checkbox"/>	518003	6.22917	0		<input checked="" type="checkbox"/>	C:\
2	Obs 35	head elevation in saturated zone	<input checked="" type="checkbox"/>	507700	6.23836	0		<input checked="" type="checkbox"/>	C:\
3	Obs 37	head elevation in saturated zone	<input checked="" type="checkbox"/>	511408	6.24164	0		<input checked="" type="checkbox"/>	C:\
4	Obs 65	head elevation in saturated zone	<input checked="" type="checkbox"/>	502766	6.2463e	0		<input checked="" type="checkbox"/>	C:\

4.3.2 Locate the MIKE HYDRO detailed time series output results


Similar to the groundwater levels, find the MIKE HYDRO (MIKE 11) detailed time series





4.3.3 Plot flows using the Plot Composer

It can sometimes be difficult to see how well the model fits the observations on this graph. Alternatively try to use the *Plot Composer* for viewing the modelled and observed flow hydrographs.

- To open the Plot Composer click *New File* on the main menu at the top below File
- Select the Plot Composer



- Click *Plot->Insert New Plot Object* and select *Time Series Plot*
- Click *New Item*  and browse to the result folder **YourFilename.she - Result Files**. Select **YourFilenameDetailed_M11.dfs0**
- Click *New Item* again and add the observed flow data **.Model Inputs\Timeflow.dfs0**
- Click OK
- To change the appearance of the graphs, right click on the graphs and select *Properties*. Click *Curves* and change line colours and markers
- To save the graph as an image click *View->Export Graphics->Save to Bitmap*
- Save the plot composer file in the Model folder as Flow.plc




4.3.4 Display the gridded results

The *Gridded Data Results Viewer* dialog lists the results you have chosen to store in the MIKE SHE results files. The XY flow vectors check box adds groundwater velocity flow vectors calculated for each cell.

The *Layer no for groundwater items* is used to select the numerical SZ layer number in groundwater outputs.

- In the *head elevation in the saturated zone* item, check on the Add XY flow vectors for the plot and then click on the *View result...* button



Note that the velocity vectors will not appear in the initial time step, but rather appear first in the second time step.

On the menu at the top:




you can play through the entire simulation, change the time step or create a video.

To step through the simulation click on  on the menu.





Note: Creating an .avi video is very time consuming, so don't start the video creation process during a course.



4.3.5 Display a time series plot at a point


To view time series in points go back to the *Gridded Data Results Viewer*

- Click *View Result...* for head elevation in saturated zone. Untick Add XY-flow vectors if these are ticked
- Click on the Time Series button  on the Results Viewer tool bar
- Click once inside the map area and then while holding down the Ctrl-key, click on each additional point where you want time series output. Each selected locations is marked with a yellow x.
- Double click on the last point. (if you only want one point then simple double click without holding down the Ctrl-key)
- Check *Display* and press OK to display the time series.



Export to a dfs0 file

- Right-click in the time series plot.
- Select *Export...* in the pop-up window.
- Check *Export* and press OK.
- Enter an appropriate file name for the dfs0 file and press Save.




The (j,k) coordinates listed at the bottom of the Results Viewer go from 0 to (nx-1) and 0 to (ny-1) in the j and k directions, respectively.


Note that the time series time steps are equal to the storing time steps. The *Detailed timeseries output* option within the *Setup Data* saves the output at every time step.

4.3.6 Extract a profile of water levels



- Press the button  on the Results Viewer tool bar to extract a profile from the simulate output item displayed
- Click in the area of interest to select the points along the profile line. Double click on the last point of the profile to terminate the profile line. The profile line is indicated with a thick green line.

Check *3D head elevation in saturated zone* and press OK.



Profile Item Selection

Item Overview

	Display	Item name	File name	Item type	Unit	Glb n
1	<input type="checkbox"/>	3D Vertical Conductivity	E:\Projects\Tr	MShe	m/s	0
2	<input type="checkbox"/>	3D Storage Coefficient	E:\Projects\Tr	MShe	1/m	0
3	<input type="checkbox"/>	3D Specific Yield	E:\Projects\Tr	MShe	()	0
4	<input type="checkbox"/>	3D Horizontal Conductivity, Y-dir.	E:\Projects\Tr	MShe	m/s	0
5	<input type="checkbox"/>	3D Horizontal Conductivity, X-dir.	E:\Projects\Tr	MShe	m/s	0
6	<input checked="" type="checkbox"/>	3D head elevation in saturated zone	E:\Projects\Tr	MShe	meter	18.8068
7	<input type="checkbox"/>	3D Calculation layers	E:\Projects\Tr	MShe	meter	0

☒ Draw M11 items


OK Cancel Apply Help

To display the computational grid on the profile, in the *Projects* pull-down menu choose

- *Active View Settings -> Profile...*

On the *Graphical Items* tab of the Dialog that appears, under Calculation layers,


- Check *Draw Calculation layer* and select *Draw as grid* to show the computational grid or *Draw as lines* to show the upper and lower surface.
- Press OK to view the selection



4.3.7 Modify visible overlays and display the finite difference mesh in result viewer


First, return to the horizontal view of *head elevation in saturated zone*, by either closing the cross-section view or switching via the *Window* pull-down menu


- In the *Projects* pull-down menu choose *Active View Settings -> Horizontal ...*



In the Dialog that appears

- Single click on the *Rectangular Grid* item: **YourFilename_3DSZ.dfs3** to view the available display options
- Under the *Miscellaneous* items, check *Element Mesh*
- Press OK to execute changes





4.3.8 Display other gridded data results

The number of gridded data items that are available depends on which modules were run and what selections you have made in the Setup. Many of these items are very useful for evaluating the integrated groundwater surface water interaction. You should explore some of these output items. For example:

- **Actual evapotranspiration** – this is the sum of all the ET components. It is useful for evaluating the spatial distribution of actual ET.
- **Depth of overland water** – typically this is a useful output for finding areas with permanently ponded water, or areas with closed depressions.
- **Seepage flow SZ – overland** – this can be used for determining where springs are occurring in the model.
- **SZ exchange flow with river** – this is useful to find losing and gaining river reaches.
- **SZ drainage flow from point** – this output maps the locations where groundwater is contributing water to the SZ drainage network.
- **Total Recharge to SZ** – this is a summary output map of all the items that contribute inflow to the SZ.

4.4 View simulation statistics


Statistics used for assessing the model fit are available in the Results menu under *Post-Processing*. The statistics are generated in HTML file format and include all the detailed time series items that have observation data.



The calibration statistics available comprise six standard statistics:

Mean (ME), Mean Absolute Error (MAE), Root Mean Square Error (RMSE), Standard Deviation of the Residuals (STDRes), Correlation Coefficient (R) and Nash Sutcliffe Correlation Coefficient (R2).

The equations for calculating the statistics are included in the Help menu and can be accessed by pressing the F1 key while placing the cursor over the *Post-Processing menu*



Note that the statistics are calculated based on the differences between the measured observations and the simulated values at the time of the observations.


- To generate statistics for the Karup model click *Post-Processing->Simulation Statistics* and click the generate statistics button **Generate Statistics**
- Change the dates if statistics for a shorter period than the full simulation period are needed
- Take a look at the statistics and assess the model performance


Name	Data type	X	Y	Layer	ME	MAE	RMSE	STDres	R (Correlation)	R2 (Nash_Sutcliffe)
Obs 5	head elevation in saturated zone	518003	6.22917e+006	1	0.842467	0.842467	0.868042	0.209158	0.831212	-12.6933
Obs 35	head elevation in saturated zone	507700	6.23836e+006	1	0.0912348	0.312092	0.428508	0.418683	0.755523	-3.30582
Obs 37	head elevation in saturated zone	511408	6.24164e+006	1	-3.44925	3.44925	3.46673	0.347712	0.729903	-288.186
Obs 65	head elevation in saturated zone	502766	6.2463e+006	1	0.332971	0.352862	0.445887	0.296557	0.882319	-2.30546
St 20.05 (outlet) (Karup River, 52000.00)	discharge in M11 q-point	499980	6.25185e+006		0.769247	0.987715	1.23841	0.970523	0.770388	0.101881


4.5 Check the water balance


The water balance utility in MIKE SHE is a vital part of the results analysis. The tool is versatile and can be used both for providing an overview of component inflows, inflows and storage changes over different periods and subcatchments and for troubleshooting any numerical issues.

4.5.1 Create a new water balance document

- Click on the New document icon, , or the File/New/File menu
- Select MIKE SHE and then the Water Balance Calculation (.wbl) document
- Click OK



- In the Project Explorer select the directory where you want to save the document, for example your model result folder: **Result\YourFilename.she – Result Files**
- Then give the file a name (e.g. SZWaterbalance) and click on the Save icon, .






In MIKE SHE, water balances are calculated by the water balance utility. This is run separately after the simulation. Creating a water balance involves 3 steps:

1. Extract the water balance data from the MIKE SHE output files
2. Create specific water balances from the extracted data
3. Evaluate the water balance output


4.5.2 Extract the water balance data

- Use the browse button and find the **.sheres** file from your simulation in your Result directory **Result\YourFilename.she - Result Files**

- Run the water balance extraction by clicking on the Extraction icon,  or by selecting the drop down window *Run* and clicking on *Extraction*. If the extraction icon does not appear at all, most likely the Run toolbar is not activated. Select the drop down window View, Toolbars and select the Run toolbar (last entry).



- Check to make sure that the Extraction ran successfully, by looking for “Normal termination” in the message window




MIKE SHE saves the results in many different files. The results are grouped by process (e.g. OL, UZ, SZ) and by output type (i.e. 2D or 3D). The extraction process reads all of the various output files and builds a set of water balance files. These files can be efficiently read by the water balance utility.

The .sheres file is an ASCII catalogue of all the output files associated with the simulation.

The type of extraction is important, as it defines what subsequent water balances can be calculated.


- Area Type – Choosing subcatchment allows you to create water balances for sub-areas in the model domain. Otherwise, the water balance is for the entire model area.
- Resolution type – By default the water balance is for the entire catchment or sub-catchment. The Single-cell option allows you to create maps of some of the water balance items.

4.5.3 Create water balance items


- On the *Postprocessing* tab, add two post processing items to the table by clicking on the new item icon, 
- Change the name of the two items, so that you can distinguish them from one another




You can set up any number of water balance calculations for a single water balance extraction. Since these are all stored in the water balance document (.wbl file), you can re-run the water balance extraction and processing after each simulation.



4.5.4 Define a Chart water balance

- Select *Chart output: Total water balance* from the list of available Water balance types
- Define a file name for the output file, for example **TotalWB.txt**. If you just type the name the program will automatically put it in the result folder
- Run the water balance by clicking on the water balance icon *run selected postprocessing*, 




The Chart output creates a graphic illustrating the water balance items (see next step). The output is sent to an ASCII .txt file, and the graphic is generated automatically by a utility that reads the txt file.

By default, the water balance is summed for the entire simulation period. However, you can easily change the water balance period, for example, to create seasonal water balances, or to remove the initialisation period.

If you defined the extraction on a sub-catchment basis, then you can select from the available sub-catchments in this Dialog.

4.5.5 View the water balance output

- On the Result tab, select the sub-item for the Chart output
- Click on the Open button beside the file path to create and open the water balance graphic
- To save the chart as an image file click File->Save Graphics... and select either Enhanced Metafiles (.emf) or Bitmap Files (.bmp)



Accumulated waterbalance from 01-01-2003 to 31-12-2007. Data type : Storage depth [millimeter].
 Flow Result File : C:\Users\dng\Documents\MIKE Zero Projects\MIKE_SHE\Karup_Basic\Karup_basic_II.she - Result Files\Karup_basic


The water balance graphic shown for the full model simulation period includes all of the non-zero water balance items in the current simulation (except for storage changes, which are always plotted).


The water balance items are all normalised to units of mm, which allows for easy comparison between the different components. If you want to convert depths of mm to volumes, you need to multiply the depth by the internal model area. That is, the total model area minus the area of the outer boundary cells. If you load the pre-processed data into the Grid Editor, select the Model and Domain item. Then, you can use the statistics function in the Grid Editor to find out the number of internal versus external cells.



Note: The sum of the water balance terms in the graphic do not add to zero. This is because some of the signs have been removed (e.g. Precipitation and ET have the same sign, but opposite inflow/outflow directions). In the water balance calculation, inflows are negative and outflows and storage increases are positive.

4.5.6 Define a time varying water balance

- Return to the Post-processing tab and select the second water balance item
- Select *Total water balance* from the list of available water balance types
- Leave the Output type as Accumulated
- Select the Output file type as a *Time series file*
- Input a filename with the .dfs0 extension, for example TotalWB.dfs0 and click on the browse button to specify the location where the file should be saved
- Run the water balance by clicking on the run water balance icon 





If you chose the Table format for the Output file instead, then the output will be in a tab-delimited ASCII file that you can open in Excel.

In this exercise we have chosen an Accumulated water balance. This sums the water balance over the simulation period.

The alternative is to define an incremental water balance, which outputs the water balance time series at each saved time step.

4.5.7 View the water balance output

- On the *Result* tab, select the sub-item for the time series output, *Time varying water balance*
- Click on the *Open* button beside the file path to create and open the water balance time series file (.dfs0)



The water balance time series file includes all of the available water balance items – most of which are also shown on the chart of the total water balance.

The cumulative water balance sums the items over all of the stored time steps. Scrolling to the bottom of the file the total precipitation is the same as in the graphical total water balance chart above. Some items have been lumped together in the chart.

Note, that the sign of the precipitation is negative and ET is positive in the time series file. This is consistent with the water balance sign convention which is:

- Outflow – Inflow + StorageChange = 0

Thus,

- All inflows to the model are negative
- All outflows from the model are positive
- A negative change in storage means that water is accumulating (an 'Inflow')
- A positive change in storage means that water is draining (an 'Outflow').

One important thing to remember is that the water balance is only an output of the saved time steps. Thus, the dynamics between the saved time steps are lost.

End of the Exercise

5 Building a MIKE HYDRO Model for MIKE SHE

The purpose of this exercise is to get to know MIKE HYDRO by inspecting and completing a MIKE HYDRO river model for a MIKE SHE model. The model is based on the stream model for Karup used in the Karup integrated MIKE SHE exercise. The exercise covers the following topics:

- Adding a river branch and boundary conditions
- Generating cross-sections from a DEM
- Routing vs dynamic branches
- Adding a weir
- Model stability
- Using MIKE View for result processing

5.1 Open the MIKE HYDRO model setup file

Ensure that you have installed the Example files in the previous Getting Started exercise, and have opened the **MIKE SHE exercises.mzp** project file.

- In the project explorer on the right hand side, locate **.\Karup_Mhydro\karup_v1.mhydro**
- Open the model by double clicking on the file. This could take a few seconds.



The MIKE HYDRO interface is similar to the MIKE SHE interface, but is more map-oriented. It includes all the model settings and parameters on the left pane.


A map of the river setup is shown in the middle window. It is possible to shift between the map and tabulated values by clicking Map or Tabular in the bottom left corner of the map window.

Model components can be selected either on the left pane or by clicking the tabs above the map window. Details of the model components are shown in the pane to the right of the map window.

Icons for zooming in/out and for inspection of stream parameter values are available from the toolbar above the map.

A *Validation* pane at the bottom shows any data input errors in setup.

- Click Zoom to working area for a visual inspection of the river setup



On the left pane the Simulation specification menu allows you to select the type of modules to include in the model setup. In this case the river module and a hydrodynamic model run have been selected. Depending on the selections, different data input menus will be available below.

- The simulation period and time control are also specified here. However for a MIKE SHE model run the simulation period is overridden by the simulation period specified in the MIKE SHE menu (see).
- Map configuration allows you to specify the coordinate system and include background maps.
- River network includes details of the river network including control structures.
- Hydrodynamic parameters contains the bed resistance.
- Boundary conditions include boundary conditions and specification of coupling with MIKE SHE.
- Initial conditions allows for initial flows and water levels to be specified.
- The Results specification menu allows you to set the output file name and storing frequency for the output. In dynamic simulations the time step for MIKE HYDRO river can be quite small, so it is often necessary to reduce the storing frequency.

5.1.1 Set the results directory

The current results directory can be changed under *Result specification->Standard results*

- Ensure that *Use default result folder* is ticked

This will create a result folder using the MIKE HYDRO name: **karup_v1.mhydro – Result Files** with the results in the **Result** folder located under MIKE SHE exercises. You can select a user defined folder instead but make sure you use a sensible name.

- Leave the result file name unchanged

Standard results

☒ Use default result folder
 Result folder path:
 ...

☐ Use default names

	RR result filename:	HD result filename:	AD result filename:	Storing Frequency	Unit
	<input type="text" value="RR_karup.res1d"/> ...	<input type="text" value="KARUP.res1d"/> ...	<input type="text" value="AD_karup.res1d"/> ...	<input type="text" value="1"/>	<input type="text" value="Time step"/>
		<input type="text" value="24"/>			<input type="text" value="Time step"/>
				<input type="text" value="1"/>	<input type="text" value="Time step"/>

5.2 Explore the branch network and add a branch

On the Setup pane select *River network* -> *Branches* or click the *Branches* menu above the map.

- Inspect the stream network in the map view.



The appearance of the river can be modified by switching from the Setup pane to the Symbology pane on the bottom left. Select Tabular view to change symbols and labels.



One tributary named Hauge creek is currently missing in the river setup. The river branches are shown on the background map as blue lines.

- Add the missing branch by clicking *File -> Import -> Import from Shapefile*. Select **.\\GIS-Data\\Hauge_creek.shp**
- Tick Branches and in the combo boxes define the attributes for Branch name, Topo-ID, Start and End chainage, Chainage unit, Flow direction and Branch type.

- Click Run, then OK, then Close

5.2.1 Convert the branch from Dynamic to Routing

- Select *Tabular* to view the branch details.
- Change Hauge creek from a Regular branch to a Routing branch in the *Branch Type* menu in the *Tabular* view

	Name	Topo ID	Start Chainage	End Chainage	Flow Direction	Branch Type	Upstr. connect. type	Upstr. Name	Upstr. Chainage	Upstr. storage ID	Downstr. connect. type	Downstr. Name
<input type="checkbox"/>	Bording creek	model cross	0	7200	Positive	Routing	Branch				Branch	Karup River
<input type="checkbox"/>	Karup River	model cross	0	52000	Positive	Routing	Branch				Branch	Hadenup River
<input type="checkbox"/>	Hadenup River	model cross	0	14200	Positive	Routing	Branch				Branch	fjeldborg creek
<input type="checkbox"/>	fjeldborg creek	model cross	0	8100	Positive	Routing	Branch				Branch	Hauge creek
<input checked="" type="checkbox"/>	Hauge creek	model cross	0	12100	Positive	Regular	Branch				Branch	



A regular branch will calculate the water level based on the Saint-Venant equation (Kinematic, Diffusion or Dynamic Wave formulations). For detailed simulations, you would generally use regular branches.

However, often it is convenient to use simpler routing formulations, where the water in the river is moved down the river – without actually calculating the water levels. Water levels are calculated afterwards knowing the flow rate in the cross-section and back-calculating a water level.

The main advantage of the routing methods is their speed. They require less data, they are numerically stable and you can use very long time steps if you want.

The downside is that the calculated water levels are less precise and hydrodynamic effects are ignored. Water levels are simply calculated based on the amount of water in the river in the current time step.


You may also combine different approaches, for instance by using simple routing techniques on the upstream, steep branches and the dynamic wave approaches on the downstream low-gradient branches.


For simplicity and to ensure the model runs fast the existing branches have all been set as routing branches.

5.2.2 Connect the branch to the Karup River

Return to the map view and

- Zoom to the confluence with the dragging zoom function in the icon bar



- Connect the branch to Karup River by clicking the Add/Edit connection button , then clicking on the end of the Hauge Creek branch and dragging the cursor over to the Karup River (you will see a cross appear on the Hauge Creek, and then a large dot when you are over the Karup River)
- Now, go to *Tabular* view and change the down stream connection chainage for Hauge creek to chainage 28600 (the location of a cross section)



5.2.3 Routing methods

To view the routing method parameters go to *River network* -> *Routing method Dialog*.

- On the last entry select Hauge creek and specify a chainage of 12090. No other changes are required.



In the *Routing Method* Dialog you only need to specify a chainage close to the end of the branch. If no other specifications are made, the model will:

- Calculate water levels using the Manning Equation assuming that the energy slope equals the bed slope derived from cross-sections (Manning numbers are specified in the HD11 file default is $M=30$ [m^{1/3}/s], $n=1/M$).
- Use the No-Discharge Transformation option, which implies that inflows are summed along the branch and transferred to the downstream end of the branch in the same time-step. This is the same as a full pipe with a unit of water entering one end and pushing a unit out the far end.
- Another discharge computation option is the Muskingum methods. It dampens the peak flows as they travel downstream, which is necessary when the travel time in the river is much longer than the time step. For example, in large river networks, it may take several days or longer for a flood wave to travel from the source to the river mouth.

Routing method (5)

Location

Branch name:

Chainage:

ID:

Water level method

Method:

Flow routing method

Method:

Delay parameter:

Shape parameter:

	Branch	Chainage	ID	Flow routing method	Delay	Shape	Water level method
<input type="checkbox"/>	Bording creek	7190	model cross	No flow routing	0	0	Manning
<input type="checkbox"/>	Karup River	51990	model cross	No flow routing	0	0	Manning
<input type="checkbox"/>	Hadenup River	14190	model cross	No flow routing	0	0	Manning
<input type="checkbox"/>	feldborg creek	8090	model cross	No flow routing	0	0	Manning
<input checked="" type="checkbox"/>	Hauge creek	12090	model cross	No flow routing	0	0	Manning



Note: In the routing option calculations are only performed at cross section locations. The Maximum dx = 5000 m specified in the *Simulations specifications->Comp control* parameters on the Grid spacing tab is not used. You may include additional routing points at different locations along a branch, but this will not be covered in this course.

In this exercise, you are using the simplest option, where no routing is used. Thus, whatever water flows into the branch network at the boundaries or as lateral inflow, will be transferred downstream in the same time-step.


MIKE SHE keeps track of and conserves mass and does not allow water to infiltrate from the river to the groundwater if the river is empty.

5.3 View and add cross-sections from a DEM

Cross section data can be viewed either by selecting *Cross sections* under *River network* and then *Tabular* view directly or by selecting a specific cross-section on the map and then switching to Tabular view. Cross sections are displayed with blue on the map and below the cross section in Bording Creek, chainage 0 has been selected (light blue).




Note: The cross section may be difficult to see with the default symbol (black line). It may therefore be necessary to change the *Symbology* to show the cross sections with dots.



Cross-sections are saved to a cross-section file .xns11 (see the General tab) which can also be viewed and edited using the MIKE11 editor. To view the file in the editor double-click on the cross section file in *Project Explorer*.

In the cross-section dialog,

- Cross-sections are identified by a Branch ID and a TOPO ID
- Cross-section data are relative to the specified Datum value
- Cross-section data are editable in the table
- The marker values in the table define the extent of the cross-section to be used in the simulation



Cross-sections for Hauge creek need to be added to the model setup. Survey data are not available but a detailed Digital Terrain Model (DTM) with a resolution of 1.6 m, available from <http://download.kortforsyningen.dk> can be used instead. For this exercise the DTM was resampled to 3.2 m to keep the file to a reasonable size. Note the example cross-section file included with the training material was generated using the original file with the fine resolution.

- First, set the coordinate system: ETRS_1989_UTM_Zone_32N. If you load the file first, the DEM may be invisible. In that case select *Symbology* and turn the colours back on.
- Load the elevation model by selecting Map configurations->Digital Elevation Model (DEM) on the left pane and select `.\\GIS data\\dtm_hauge_clp.asc`. This may take a few seconds as the file is large.
- Tick on the Use DEM for

☒ Use DEM for cross section creation
☐ Use DEM for river tracing and catchment delineation

Digital Elevation Model (DEM)

File format: ESRI ASCII

DEM: C:\Work\main\Products\Source\Manuals\MShe\flowmodel\exercises\ExerciseFilesTest\Karup_MHydro\GIS data\dtm_hauge_clp.asc

Coordinate system: ETRS_1989_UTM_Zone_32N Z-value unit: meter

Cross sections

Cross section creation

☐ Use bilinear interpolation
☒ Use half cell size for spacing between points
Maximum spacing between points: 10
Maximum number of points: 100

DEM cell size: 3.2

Cross section plots

☐ Show DEM together with cross section plots
☒ Use cell size for spacing between points
Spacing between points: 10

- Click *Map* to view the DEM.

Routing method (5)

Location

Branch name:

Chainage:

ID:

Water level method

Method:

Flow routing method

Method:

Delay parameter:

Shape parameter:

	Branch	Chainage	ID	Flow routing method	Delay	Shape	Water level method
<input type="checkbox"/>	Bording creek	7190	model cross	No flow routing	0	0	Manning
<input type="checkbox"/>	Karup River	51990	model cross	No flow routing	0	0	Manning
<input type="checkbox"/>	Haderup River	14190	model cross	No flow routing	0	0	Manning
<input type="checkbox"/>	feldborg creek	8090	model cross	No flow routing	0	0	Manning
<input checked="" type="checkbox"/>	Hauge creek	12090	model cross	No flow routing	0	0	Manning




A DEM can be defined in two file formats either as a ESRI ASCII or a dfs2 file. For ESRI ASCII files the coordinate system and z unit for the file must be specified. If a .dfs2 is chosen these parameters are taken from the dfs2 file definitions.


By ticking *Use DEM for cross section digitisation* different options are available in terms of interpolation and number of points to extract per cross-section.

It is also possible to set additional parameters for using the DEM for river tracing and catchment delineation.

- To extract cross sections for Hauge creek select *Tools->Auto generate cross sections...* from the Tools menu
- Specify an interval of 3000 m and a width of 100 m. Tick *Use bilinear interpolation*
- Click Generate and close the window





- Click on the Map to view the location and length of the cross-sections.
- In *Tabular* view click *General* -> *Recompute* all to compute processed data for the new cross sections
- Before saving the model save the cross section file using a different name. Go to the project explorer, right click on **karup0.xns11**, copy it, and then change the name to **karup1.xns11**.
- Go back to MIKE HYDRO and select **karup1.xns11** in *Cross sections* -> *Tabular view*



The cross sections are too wide and only the main channel geometry should be included in the model. To constrain the extent of the cross section used in the simulation the bank markers will have to be moved. This can be done in different ways. Embankment lines can be added either by importing them as shapefiles or by digitising them in MIKE HYDRO. Alternatively the markers can be modified manually either directly in MIKE HYDRO or by using the older MIKE 11 cross section editor.

For this exercise the cross sections will be modified in MIKE HYDRO:

- Go to *River network->Cross sections* and select the *Tabular* view window
- Click Hauge creek/model cross and select chainage 0
- On the *Cross section properties* menu select *Raw data*
- Click on a point  under Marker and click OK. The selected point will be shown in red on the graph (see below)
- Hauge creek is quite small and the DEM is not sufficiently detailed to include the channel everywhere. As a guide set the width to app. 5-20 m.
- It may be necessary to click on several points to find the correct location. Once the left bank has been identified tick (1) *Left levee mark*
- Do the same for the bottom of the stream (2 *Lowest point/River alignment*) and right bank (3 *Right levee bank*)
- Repeat the process for all the cross-sections in Hauge creek
- Once all the markers have been set, save the MIKE HYDRO project.




Note: In Hauge creek the cross-sections are now located very close together at the confluence with a distance of 100 m. This is fine for using the simple routing method but for a fully hydrodynamic run this could mean that the model becomes unstable. In that case it may be preferable to remove the cross section at chainage 12000.

5.4 Add boundary conditions

Boundaries can be viewed either by selecting Standard boundaries directly or by selecting a boundary point on the map and then switching to Tabular view. The boundaries are shown with red dots on the map.

Now take a quick look at the boundary specifications in the model. All the upstream ends (Chainage = 0) are defined as Inflow boundaries with zero inflow. The downstream mouth of the river is defined as a water level boundary.


- Add another Inflow boundary for Hauge creek (Chainage = 0) with zero inflow by selecting  boundaries on the Boundary menu above the map and clicking on the upstream end of the branch in the *Map* window
- Select Tabular and change the type from Water level to Discharge
- Specify a small discharge of 0.005 m³/s. This will reduce the risk of the model running dry



Specifying a small influx as a boundary condition will prevent the model from running dry and will also keep the model more stable. This is only an issue when using a regular branch with Kinematic, Diffusion or Dynamic Wave formulations.

5.5 MIKE HYDRO – MIKE SHE coupling

In the *Boundary conditions* -> *MIKE SHE Couplings* Dialog, you specify which MIKE HYDRO branches will be coupled with MIKE SHE. You may choose to include some of the river branches or all of them, or even just part of a branch.

- Add Hauge creek by clicking  in *Tabular* view and select Hauge creek
- Change DS chainage to 12100 to couple the full length of the branch to MIKE SHE
- Change the conductance option to River bed only and set the leakage coefficient to 10⁻⁶ sec⁻¹



The coupling specification includes the definition of the river-aquifer exchange, including the river bed leakage coefficient. The river leakage can also depend on the hydraulic conductivity of the aquifer material when the MIKE SHE cell size is much bigger than the river width.

The exchange between MIKE SHE and MIKE HYDRO is one-way (default setting). Overland surface water will flow into the MIKE river, but water will not flow back onto the ground surface if the river floods. Overland flooding can be included, using one of two options:

- Cells can be defined by flood codes, where they will be flooded if the elevation of the MIKE SHE cell is below the water level in the nearest river H-point.

- Alternatively, you can allow overbank spilling. In this case, the river will discharge the water onto the ground surface based on a weir formula.

MIKE SHE Couplings (5)

☒ Include MIKE SHE coupling

Location

Branch name: Hauge creek

Upstream chainage: 0

Downstream chainage: 12100

Overland-river exchange

Weir coefficient: 1.838

Weir exponential coeff: 1.5

Min. upstream height above bank for full weir width: 0.1

☐ Allow overbank spilling from river to overland domain

Min. flow area for overbank spilling: 0

River-aquifer exchange

Conductance: River bed only

Leakage coeff: 1E-06

Linear reservoir exchange: Gaining river

Inundation

Flood area option: No flooding

Flood code: 0

Bed topography: Use grid data

Bed leakage: Use river data

	Branch name	US chainage	DS chainage	Conductance	Leakage coeff.	Linear reservoir exchange	Weir coeff.	Weir exp. Coeff.	Min US height	Overbank spilling	Min. flow area	Flood area	Flood code
<input type="checkbox"/>	Bording creek	0	7200	Aquifer + rive...	1E-05	Gaining river	1.838	1.5	0.1	<input type="checkbox"/>	1	No flooding	-99999
<input type="checkbox"/>	Karup River	0	52000	Aquifer + rive...	1E-05	Gaining river	1.838	1.5	0.1	<input type="checkbox"/>	1	No flooding	-99999
<input type="checkbox"/>	Haderup River	0	14200	Aquifer + rive...	1E-05	Gaining river	1.838	1.5	0.1	<input type="checkbox"/>	1	No flooding	-99999
<input type="checkbox"/>	Feldborg creek	0	8100	Aquifer + rive...	1E-05	Gaining river	1.838	1.5	0.1	<input type="checkbox"/>	1	No flooding	-99999
<input checked="" type="checkbox"/>	Hauge creek	0	12100	River bed only	1E-06	Gaining river	1.838	1.5	0.1	<input type="checkbox"/>	0	No flooding	0

5.6 Run a simulation

To test that the model has been set up correctly, it is necessary to run the model.

- Run the model by selecting *Run->Simulation* from the main menu
- Inspect the run messages on the *Simulation* pane and make sure the model run finished without errors



To test the performance of the MIKE HYDRO model without MIKE SHE it is necessary to run the model with some inflows at the boundaries. For a simple routing model, simply running and checking the model will mostly be sufficient.

For a fully hydrodynamic solution it is sometimes necessary to run it with an inflow hydrograph upstream in order to test whether the model is stable for the full flow range. It is also recommended to generate a result file with small boundary inflows that can be used as a HOT-start file to prevent initial instabilities.

Standard boundaries (6)

Boundary ID: Location Branch name:

Type: Chainage:

Location type: Dwstr. chainage:

HD boundary

☒ Include boundary

Input type: Scale:


File: Item:





Runoff flow type	Include HD	HD input type	HD scale	HD value	HD file name	HD file item	Include AD	Use
Total runoff	<input checked="" type="checkbox"/>	Time varying	1	0	C:\data\MIKE S...	q=0	<input type="checkbox"/>	
Total runoff	<input checked="" type="checkbox"/>	Time varying	1	0	C:\data\MIKE S...	wf_steady	<input type="checkbox"/>	
Total runoff	<input checked="" type="checkbox"/>	Time varying	1	0	C:\data\MIKE S...	q=0	<input type="checkbox"/>	
Total runoff	<input checked="" type="checkbox"/>	Time varying	1	0	C:\data\MIKE S...	q=0	<input type="checkbox"/>	
Total runoff	<input checked="" type="checkbox"/>	Time varying	1	0	C:\data\MIKE S...	q=0	<input type="checkbox"/>	
Total runoff	<input checked="" type="checkbox"/>	Constant	1	0.005			<input checked="" type="checkbox"/>	


5.7 View the results

To check the model results, open MIKE View by going to the Start menu and select *MIKE View 2017->MIKE View*

- Load the results by selecting the file type as .res1d and the select your latest simulation results.



- Click  to select and plot a time series of discharge at the downstream confluence. This should show a constant stream flow of $0.025 \text{ m}^3/\text{s}$
- Click  and select a branch to plot a cross section showing the water level. Click on the branches you want to view and press the Ctrl key and click in the view to complete the cross sectional plot
- Click  to run through the simulation and  to pause at a desired time




5.8 Add a weir structure

You will now add a weir to the main branch Karup River. The weir is a broadcrested weir located at river chainage 28550. The width is 2 m and the sill level is 31.5 m AOD.

5.8.1 Change branch type

To include a structure in the model, the river branch type for Karup River will first have to be changed to a regular branch and a dynamic solution to be able to account for back water effects. The upstream tributaries (all the other branches) can be kept as routing branches:

- Select *River network*-> *Branches* and change *Branch Type* from Routing to Regular for Karup River in the Map view
- Go to *Routing Method* and delete Karup River by selecting the branch and then clicking  Delete
- Check the wave approximation method in Simulation specification->Computational control parameters. Set the method to Dynamic (default)
- Go to *Time step control* and change the time step length to 5 minutes
- Save the model and run the model to ensure that the model is numerically stable

5.8.2 Add the weir dimensions




A number of different weir formulations are available: Broad Crested, Villemonte Formula, Honma Formula and Extended Honman Formula.


The geometry for broad crested weirs can be defined in two different ways:


- Level-Width: The weir geometry is specified as levels (relative to the datum) and corresponding flow widths.
- Cross Section DB: The weir geometry is specified as a cross section in the cross section editor. A cross section with a matching branch name, Topo ID and chainage must exist in the applied cross section file.

Note: Since a weir is defined as a structure causing a contraction loss and subsequently an expansion loss, the geometry of the weir must be such that the cross sectional area at the weir is less than the cross sectional area at both the upstream and the downstream cross section for all water levels.

You can now add the weir. In this exercise, the weir geometry uses the Level-Width option:

- Go to *River Network*->*Structures* and select *Weirs*->*Tabular view*
- On the *General* tab click  to add the weir and change the ID to Karup_spill
- Change the Branch to Karup River and set the chainage to 28850
- Leave the *Type* and *Weir type* unchanged
- Under Geometry select Level-Width (default) and set the Datum (sill level) to 31.5.

- Specify the weir dimensions by clicking  adding two lines:
 - Level=0, Width = 2
 - Level=10, Width = 2




ID	Branch	Chainage	Type	Weir type	Valve	Geometry type
1	Karup River	28550	Regular	Broad Crested	None	Level-Width

- To check the location of the weir in relation to cross sections go to the *Map* view. The location of the weir is shown as a white square.

There is a cross-section 50 m below the weir but none upstream of the weir. As survey data is not available upstream of the weir, you can create a copy of the downstream cross section at chainage 28600 and add it upstream of the weir:


- Go to *River network->Cross sections* and right click on the cross section in *Map* view
- Select copy and specify a chainage of 28500
- Then, save the setup





- Go back to the *Weir* menu and select *Flow conditions* in the *Tabular* view.
- Click *Calculate Q/h relations*

5.9 Re-run the model

To look at the effects of the weir the model will need to be re-run and the results loaded into Mike View.

- Run the model by selecting *Run->Simulation* from the main menu
- Inspect the run messages on the *Simulation* pane and make sure the model run finished without errors
- Re-open Mike View and load the results for **Karup1.res1D**
- Click  and select Karup River. Press the Ctrl key and click in the view to complete the cross sectional plot. Select Data type = Water level

Note: The Maximum dx = 5000 m specified in the *Simulations specifications->Comp control* parameters on the *Grid spacing* tab is now used for the Karup River branch.



6 Application Example: Impact of Groundwater Pumping

This exercise shows how groundwater pumping affects groundwater levels and stream flow. The model is based on the MIKE SHE model for Karup developed in the first exercise. If you have completed the first exercise, you can use your own model.

Otherwise, if you want to use an existing model, ensure that you have installed the Example files in the previous Getting Started exercise, and have opened the **MIKE SHE exercises.mzp** project file. Then,

- Go to the project folder **Karup_Basic** and open **Karup_basic.she**

In either case,

- Rename and save the model using the *File/Save As...* command to another name. From now on in the exercise, we will refer to this model as **YourFilename.she**

6.1 Set up a new base case scenario

First, we need to setup and run a new model without groundwater pumping so we can compare the results when we turn on the pumping.

6.1.1 Redefine the horizontal grid resolution

To analyse the effects of an abstraction we need to refine the grid.

A very powerful feature of MIKE SHE is that you can change the horizontal grid without redefining your model parameters. Consequently you can perform sensitivity analysis of your model grid and grid resolution in a way that is impossible with most other modelling user interfaces.

Note: a finer grid is possible, but the simulation time will increase substantially.



Demo Note: the demo version is restricted to a maximum of 70x70 cells, so you will not be able to pre-process or run the model with the refined grid but can continue with the 500m grid.

In the *Model Domain and Grid* Dialog of the Setup tab:

- Double the number of grid cells in the X and Y directions
- Set $NX = 130$ and $NY = 140$
- Change the *Cell Size* to 250 m

Model Domain and Grid

☐ Catchment defined by Dfs File
☒ Catchment defined by Shape File

C:\data\MIKE SHE training material\Karup_Basic\MIKE_SHE\Model ...


Create...


Catchment size and orientation

NX: 130 NY: 140 Cell Size: 250 [m] Rotation: 0 [Deg. Counter clockwise]

Catchment origin and map projection

X0: 493900 [m] Y0: 6220750 [m] Map Projection Type: ETRS_1989_UTM_Zone_32N




- To ensure the model data can be converted to 250 m click on the  icon on the main menu to start the pre-processor.
- Verify in the pre-processor tab that all of the input data has been converted to a 250m grid



Note: a number of warnings may appear as values are missing in some locations along the boundary. The pre-processor automatically fills in the gaps with neighbouring values.

6.1.2 Add a new stream flow observation

Add a new stream observation location so that you can observe the impact of abstraction on the local stream flow.

- Go to *Storing of results* on the left pane and select *Detailed M11 timeseries output*
- Click the add button  to add a new line
- Specify the *Name*= Pindsobro and change the *Data type* to Discharge
- Type in the *Branch name*=Karup River and set the *Chainage* to 18237.5 m

Detailed M11 timeseries output

Minimum output time step: 0.5 [hrs]

Import...


	Name	Data type	Branch name	Chainage	Incl. Obs. Data	Obs. Data Filename		
1	St 20.05 (outlet)	Discharge	Karup River	52000	<input checked="" type="checkbox"/>	C:\data\...\Timeflow.dfs0	Edit...	New...
2	Pindsobro	Discharge	Karup River	18237.5	<input type="checkbox"/>		Edit...	New...



The specified *Chainage* needs to be at or close to the location of a MIKE HYDRO river computational discharge point. The pre-processor will check the distance and if it is greater than a prescribed tolerance a Warning will be written in the log file.

6.1.3 Add a new groundwater observation

Add a new groundwater observation location so that you can observe the impact of abstraction on the local groundwater level.


- Go to *Storing of results* on the left pane and select *Detailed timeseries output*
- Click the add button  to add a new line
- Specify the *Name*= Obh_Pindsobro and change the *Data type* to Head elevation in saturated zone
- Type in the coordinates X=513950 and Y=6230800 and Depth=5 m

Detailed timeseries output

Minimum output time step: 0.5 [hrs]

Import...

	Name	Data type	New plot	X	Y	Depth		Incl. Obs. Data	Obs. Data Filename		
1	Obs 5	head elevation in saturated zone	<input checked="" type="checkbox"/>	518003	6.22917	5		<input checked="" type="checkbox"/>	C:\data\...\TimeHeadObservations.d	Edit...	New...
2	Obs 35	head elevation in saturated zone	<input checked="" type="checkbox"/>	507700	6.23836	5		<input checked="" type="checkbox"/>	C:\data\...\TimeHeadObservations.d	Edit...	New...
3	Obs 37	head elevation in saturated zone	<input checked="" type="checkbox"/>	511408	6.24164	5		<input checked="" type="checkbox"/>	C:\data\...\TimeHeadObservations.d	Edit...	New...
4	Obs 65	head elevation in saturated zone	<input checked="" type="checkbox"/>	502766	6.2463e	5		<input checked="" type="checkbox"/>	C:\data\...\TimeHeadObservations.d	Edit...	New...
5	Obh_Pindsobro	head elevation in saturated zone	<input checked="" type="checkbox"/>	513950	6230800	5		<input type="checkbox"/>		Edit...	New...




6.1.4 Run the simulation

For this example the simulation period will be reduced to one year, as run times will otherwise be too long:

- In the *Simulation period* menu specify the *Start date* and *End date*:
 - Start Date: 1 January 2000
 - End Date: 31 December 2000
- On the Toolbar, click on the **PP** icon to re-run the Pre-processor and then on the Water Movement **WM** icon to run the simulation
- Click OK

Note if the simulation is taking too long it can be stopped by clicking the red button below.



- Check the model run log files to ensure the model finished without any errors.
- Go to the results folder **Result\Yourfilename.she - Result Files** and double click on **YourFilename_WM_Print.log**
- Scroll to the bottom of the file and check whether the different model components converged. Likely some of the components will have exceeded the maximum number of iterations. The impact of this can be evaluated later with the water balance tool.

6.1.5 Check the stream flow and observation borehole time series plots

After successfully running the model:

- Click on the *Results* Tab located at the bottom of the Navigation Tree and select *Simulation Results->MIKE 11 Detailed Time Series*
- Click Plot no. 2 to ensure the stream flow plot has been generated and looks reasonable

Do the same for the groundwater observation borehole:



- Click on the *Results* Tab located at the bottom of the Navigation Tree and select *Simulation Results->MIKE SHE Detailed Time Series*
- Click Plot no. 5 to ensure the observation borehole plot has been generated and looks reasonable


6.2 Create a pumping scenario


Before adding the pumping well, you need to create another scenario setup so that the model results can be compared.

- Rename and save the model using the Save As... command:
YourFilename_abs.she

The river results will also change, so we also want to create another MIKE HYDRO setup:


- Go to the *Rivers and Lakes* menu on the left pane and click the  button. This will open the MIKE Hydro editor.
- Select *Result specifications* at the bottom of the left pane click on the *Standard results* tab
- Change the HD result file name to **KARUP_abs.res1d**
- Click *File->Save as..* on the main menu and save the file as **karup_II_abs.mhydro**
- Go back to the MIKE SHE *Rivers and Lakes* menu and use the browse button  to select the new file





On the Toolbar, click on the  icon to re-run the Pre-processor to ensure that the model setup is correct.

6.3 Add the groundwater abstraction

In this step, use the Well Editor to add a well beside the stream.

- First go to the *Saturated zone* data tree item to include abstractions and tick *Include pumping wells*
- A new item in the data tree, *Pumping Wells*, will now appear below Drainage.
- Select *Pumping Wells* and click the button  to create a new well database file. This will open the Well Editor in a new window
- Browse to the folder **.Model Inputs** and name the file **MyWells.wel**. Click Save






- To open the database file click . This will open a new window with the empty database file




The new file automatically shows a map of the catchment outline and the background map specified in the *Display* menu. The overlays are carried over from the model Setup Tab. You cannot add or modify overlays directly in the Well Editor. This must be done from the Setup Tab. Right clicking on the map, allows you to control the zoom and a number of other functions. The interactive map displays all of the wells in the well file. Clicking on individual wells will select the corresponding item in the table of well locations. Similarly, selecting an item from the list will change the icon of the well on the map to a red square.


To add a new well,


- Click the button  to add a new line under Well locations. Then update the line:
 - Name = Pindsobro
 - Xcoor = 513900,
 - Ycoor = 6230750,
 - Level = 62 m and
 - Depth = 60 m.
- Next, in the Filter table, click the add button  and add the filter settings:
 - Top = 25 m and
 - Bottom = 15 m




You can see the location of the well on the map view, and the well screen in relation to the geological layers and lenses, as well as the numerical grid layers.

- To specify the abstraction rate, click the browse button  and select **abs.dfs0** and select Item: Pindsobro. Click OK



- To view the abstraction rate click the edit button . Inspect the .dfs0 file
- Close the abstraction time series file

From the Toolbar at the top and *Import* it also is possible to import well data from a tab delimited ASCII file:



Note: Zeus data is a specialized data format from the Geological Survey of Denmark and Greenland.

- Save and close the well file
- To view a map showing the location of the abstraction in the MIKE SHE file tick *Show well location map*

6.4 Run the pumping simulation

Before running the simulation, we need to add the results from the original scenario as observations in the pumping scenario.

6.4.1 Add the stream flow result file

To see the difference in stream flow with and without abstraction in the MIKE SHE menu system, add the result file from the model run without the abstraction to the stream plot at Pindsobro:

- Go to *Storing of results* on the left pane and select *Detailed M11 timeseries output*
- On the second line tick *Incl. Obs. Data*
- Click the browse button and find your detailed time series results for the previous simulation without the abstraction:
YourFilename_DetailedTS_M11.dfs0
- Before closing the Selection dialog, under *Items* select Pindsobro
- Click OK

6.4.2 Add the head result file

To see the drawdown caused by the abstraction, you can add the result file from the model run without abstraction to the head elevation plot at Pindsobro.

- Go to *Storing of results* on the left pane and select *Detailed timeseries output*
- On the second line tick *Incl. Obs. Data*
- Click the browse button and find your detailed time series results for the previous simulation without the abstraction:
YourFilename_DetailedTS_SZ.dfs0
- Under *Items* select Obh_Pindsobro
- Click OK



Adding time series of modelled heads from another model run can be done in two different ways, depending on whether observation data is available.

1. In the first case where no observation data is available, you can add the previous results as observations.
2. Alternatively, you can add a new line below the results item and unclick the *New plot* checkbox. This way it is possible to add both observation data and multiple simulation results to the same graph. This may be useful during calibration where you want to compare the results from more than one run to the observations.

6.4.3 Run the simulation

On the Toolbar, click on the **PP** icon to re-run the Pre-processor and then on the Water Movement **WM** icon to run the simulation


When the model is finished, check the log file to ensure the model finished without any errors: **YourFilename_abs_WM_Print.log**

6.5 Analyze the change in stream flow

6.5.1 View the detailed time series output results


To view the stream flow at Pindsobro click on the *Results* tab at the bottom of the menu and then *Simulation Results->MIKE 11 Detailed Time Series*

The black line shows the discharge at Pindsobro for the current model run without the abstraction compared with the results from the model run including the abstraction (plotted as observation points). It is clear that the abstraction is having a large impact on stream flows all year round due to the vicinity of the well to the stream and high connectivity between the stream and aquifer.



- To view the groundwater level close to the Pindsobro abstraction click on go to the *MIKE SHE Detailed Time Series, Plot no 5*

The graph shows a significant drawdown in head due to the abstraction.



6.5.2 Calculate the difference in the stream flow

To calculate the difference in flow at Pindsobro without and with pumping:

- Open the **YourFilename_DetailedTS_M11.dfs0** in the results file folder for the refined (250m) model **without** abstraction:
- Click *Edit->Properties* in the top Menu
- Add two new lines to the table by clicking on the **Append** button and update the new lines as follows:

Item Information


	Name	Type	Unit	TS Type
1	St 20.05 (outlet)	Discharge	meter ³ /se	Mean Step Accumulated
2	Pindsobro	Discharge	meter ³ /se	Mean Step Accumulated
3	Pindsobro_abs	Discharge	meter ³ /se	Mean Step Accumulated
4	Diff_q	Discharge	meter ³ /se	Mean Step Accumulated

< >


Insert Append Delete Item Filtering...


- Click OK
- From the top Menu, use File->Save as.. and save the file as **Q_diff.dfs0**

Now,

- Open the **YourFilename_abs_Detailed_TS_M11.dfs0** in the results file folder for the refined (250m) model with abstraction:
- Select the second column named Pindsobro and copy the data to the clip board (^C)
- Return to your **Q_diff.dfs0** file and paste (^V) the data in the third column
- Save  the file

Now, you need to use the functions option in the Time Series Editor to calculate the difference in flow between the two columns:

- click  on the toolbar at the top
- Type in the Current Expression textbox: $i4=i2-i3$






- Click OK and save file

This should immediately fill in the fourth column with the difference between Column 2 and 3.

6.5.3 Use the Plot Composer to plot the impact on stream flow


To plot the flows and the differences using the Plot Composer tool:

- Create a new Plot Composer document from *File/New* in the top menu or use the New File icon, and then select the Plot Composer icon in the list of MIKE Zero documents.
- Insert a new plot using either *Plot->Insert New Plot Object* and select *Time Series Plot* or by clicking on the New Plot icon, , and selecting the Time Series Plot
- In the Properties dialog that appears, click *New Item*  and select your **Q_diff.dfs0** from the list
- Under *Any Item Type* select Pindsobro, Pindsobro_abs and Diff_Pindsobro
- Click OK



- To change the appearance of the graphs, right click on the graphs and select *Properties*. Click *Curves* and change line colours and markers
- To save the graph as an image click *View->Export Graphics->Save to Bitmap*
- Save the plot composer file as **Q_diff.plc** in the **Model** folder

You should get a plot something like this:



6.5.4 Use MIKE View to calculate the change in stream flow accretion

We want to look at the effect of the pumping on stream flow accretion along the Karup River at different times. To do this:


- Use Windows Explorer to navigate to the results folder for the MIKE Hydro simulation **with** abstraction, and then double click on the file: **KARUP_abs.res1d**
- Click OK to load all the data




This should open the MIKE HYDRO result file in MIKE View. If for some reason this does not work, you can also open MIKE View from the Program menu and load the file. If the file is not yet loaded,

- add the MIKE Hydro result file (*.res1d) abstraction to MIKE View using the File/Add in the top menu.
- Click OK to load the result file


Once MIKE View is open, with the results loaded, we want to plot the stream flow accretion with and without pumping. To do this:


- Click the profile button  on the main menu to draw a profile
- Click on the middle branch of Karup stream (the branch turns green), press the Ctrl key, click in the view, and select 'Yes' to create the longitudinal plot.
- Select Data Type=Discharge, and click OK



Now, to add the **no-pumping** MIKE Hydro *.res1D

- Click on the *Options* icon



- Select the *Graphical Items* tab
- Click the Add button . Then select Dynamic Item, File= **Karup_nat.res1d (your file without pumping)** and Item=Discharge. Then click OK.


- You may want to choose a different line colour etc, change the Actual name, etc. Then click OK

To save the plot layout, right-click on the map view and select *Save complete layout*.

- Save the file as **Stream_flow_acc.CLA**

You can then reload this file in future to recreate the plot.

- To re-load the file click File->Reload complete layout...and select **Stream_flow_acc.CLA** located in **.\\Result**
- Click OK and OK to load the MIKE HYDRO result files



6.6 Analyze the well drawdown

To evaluate the radius of influence of the well, we can look at the well drawdown in space and time. To do this we need to subtract the no-pumping results from the pumping results. There are basically two ways to do this.


- **Grid Editor** - The most direct way is to subtract the files from within the Grid Editor
- **Grid Calculator** - However, if you want to do this regularly, say at the end of every simulation you can set up a script using the Grid Calculator Tool in the MIKE SHE Toolbox.

6.6.1 Calculate drawdown using the Grid Editor

To calculate the difference in groundwater levels at Pindsobro without and with pumping:


- Open the **YourFilename_3DSZ.dfs3** in your **Results** directory, and save the file to a new name (eg **Drawdown.dfs3**) using the File/Save as... menu function.


Demo note: in Demo mode, you will not be able to save any changes to the dfs3 file




Now, to subtract the two results files:

- Click *Tools->Copy File into Data* on the main menu





- Select the *File to Copy* using the browse button , and find your no-pumping **_3DSZ.dfs3** results file
- Under *Operation Type*: choose the minus sign, “-“
- Click OK, and then Yes to continue




This process will change every value in every time step, by subtracting the two values. The result will be a dfs3 containing only the differences.

You can view the new values by

- Clicking on the Time Step Forward and Backwards buttons  to view the drawdown at different times
- Zoom in by right clicking on the map



MIKE SHE includes sophisticated tools for managing gridded data as well as time series data. This is very useful for time varying distributed parameters, such as precipitation that is interpolated from rain gauge data, or distributed recharge calculated by third party programs.

- The grid editor is a split window that can be dragged sideways to make the map smaller or larger. The table of values on the right side reflects the highlighted grid shown on the map.
- Ranges of values can be searched for, selected and changed using the select and unselect tools, , plus the *Tools/Set Value...* Dialog.

Important Note



The grid editor is a generic grid tool for all DHI Software, and was originally developed for the Marine programs MIKE 21 and MIKE 3. However, this often leads to confusion in the node and layer numbering because MIKE 21 and MIKE 3 use a different numbering system.


Node numbering: In the Grid Editor (and in MIKE 21 and MIKE 3) the nodes are numbered starting in the lower left from (0,0), whereas **in the MIKE SHE dialogs and log files the nodes are numbered starting in the lower left from (1,1).**

Layer numbering: In the Grid Editor (and in MIKE 21 and MIKE 3) the layers are numbered starting at the bottom from 0, whereas **in the MIKE SHE dialogs and log files the layers are numbered starting at the top from 1.**


6.6.2 Calculate Drawdown with the Grid Calculator

. To make this conversion, you can:

- Click on the New File icon, or the *File/New/File...* top menu. Then select the MIKE SHE toolbox.



- Now select *Util/Grid Calculator*



- Add a title if you want and then click 

In the Calculation Setup dialog that appears:

	Variable Name	Data File	Item	From	To
1	A	C:\Users\dng\Documents\MIKE Zero Projects\MIKE_SHE\Karup_Basic\Karup_b	head elevat		
2	B	C:\Users\dng\Documents\MIKE Zero Projects\MIKE_SHE\Karup_Basic\Karup_b	head elevat		
3					
4					
5					
6					
7					
8					

Output specification

Description : Drawdown

File name : drawdown.dfs3

Item type : Water Depth Item unit : meter

Expression

A-B

Example: (Level1 - Level2) * Conduc

< Back Next > Cancel Help

- Browse to the two dfs3 head results files (pumping and no pumping) and add them to the list of items with a Variable name of A and B. Note that you will need to change the Files of type to Grid series files (.dfs3). And, you will need to select the Item Type

Open

Look in: Karup_basic_IL_250m.she - Result Files

Name	Date modified	Type
Karup_basic_IL_250m_3DSZ.dfs3	28-06-2017 11:16	MIKE Zerc
Karup_basic_IL_250m_3DSZflow.dfs3	28-06-2017 11:16	MIKE Zerc
Karup_basic_IL_250m_3DUZ.dfs3	28-06-2017 11:16	MIKE Zerc
Karup_basic_IL_250m_PreProcessed_3DSZ.DF...	28-06-2017 11:10	MIKE Zerc

File name: Karup_basic_IL_250m_3DSZ.dfs3

Files of type: Grid series files (*.dfs3)




Select Item Period Info. Item Info. Constraints Info.

Title: 3D SZ results

File Type: Equidistant Time Axis

Any Item Type	Item
	head elevation in saturated zone

Cancel OK

- Add a Description, if you like, and a Filename, such as **drawdown.dfs3**
- Select the Item type = Water Depth, with a Item Unit = meter
- Now set up the Expression “A-B”. **Note that the variable names are case sensitive**
- Then, click 
- On the last page, click  to run the actual conversion.
- Click OK in the window saying successful completion
- Click  to close the tool.



The Grid Calculator is a very useful tool. It allows you to do complex, multi-step, operations on files. It also has limited statistical functions, as well as a Group function. Together these allow you to create sophisticated analyses, such as the minimum monthly water levels over your simulation, or the number of days that are area is flooded per year.


You can also save the Toolbox tool and run it at the end of your simulation. You can also run the Grid Calculator from a command prompt or batch file directly.

6.6.3 Plot the drawdown using the Plot Composer


You can look at the drawdown in the Grid Editor, but if you want to create a report plot, you can use Plot Composer.

However, the Plot Composer does not support dfs3 files. Therefore, first you need to convert the drawdown file from a .dfs3 file to a .dfs2 file. To make this conversion, you can:

- Click on the New File icon, or the *File/New/File...* top menu. Then select the MIKE ZERO toolbox



- Now select *Extraction/2D Grid from 3D files*




- Add a title if you want and then click
- Browse to your **Drawdown.dfs3** file and click
- Click again for all time steps, and click again for the default layer
- Specify a File Name and Title for the output file (eg **Drawdown.dfs2**). Then, click
- On the last page, click to run the actual conversion.
- Click OK in the window saying successful completion
- Click to close the tool.




If you save the tool setup, then you can run it again without having to update it. You can also run a saved toolbox setup from a batch file.

Now open a new Plot Composer document to create a drawdown map as you did before.

- Click Plot->Insert New Plot Object and select Grid Plot
- In the *Grid Plot Properties* menu select the *Master File* as **Drawdown.dfs2**
- Select the *Contours* menu
- Tick *With labels* and tick *Plot color Legend*
- Click OK
- To view the drawdown at different times first select the Animate menu at the bottom left
- Use the play menu to move through the file
- To change the colours or layout go back to the menu and right click on the map. Select *Properties*. Play with the colour scale.
- To add the stream to the map right click on the map and select *Add/Remove layers....*
- Click the add button to add a new item


- Change File type to Shapefile and in **.\\Model Inputs\\GIS data** select **karup_georef.shp**
- Click 
- To save the graph as an image click **View->Export Graphics->Save to Bitmap**
- Click **File->Save as..** and save the file as **Drawdown.plc**





6.7 Analyze the change in water balance

You can use the water balance tool to look at the impact of the abstraction.


6.7.1 Create a new water balance document

- Click on the New document icon, , or the File/New/File menu
- Select MIKE SHE and then *the Water Balance Calculation (.wbl) document*




- Click OK
- In the Project Explorer select the directory where you want to save the document
- Then give the file a name (e.g. Waterbalance) and click on the Save icon 


6.7.2 Extract the water balance data

- Use the browse button and find the **.sheres** file from your simulation in your Result directory
- Run the water balance extraction by clicking on the Extraction icon, , or by selecting the drop down window *Run* and clicking on *Extraction*.
- Check to make sure that the Extraction ran successfully, by looking for "Normal termination" in the message window

6.7.3 Define a Chart water balance

- As there will only be only item it is not necessary to add more items on the *Postprocessing* tab
- Select *Chart output: Total water balance* from the list of available Water balance types.
- Define a file name for the output file, for example Water_balance_abs.txt

- Run the water balance by clicking on the water balance icon *run selected postprocessing*, 





The Chart output creates a graphic illustrating the water balance items (see next step). The output is sent to an ASCII .txt file, and the graphic is generated automatically by a utility that reads the txt file.

By default, the water balance is summed for the entire simulation period. However, you can easily change the water balance period, for example, to create seasonal water balances, or to remove the initialisation period.

If you defined the extraction on a sub-catchment basis, then you can select from the available sub-catchments in this Dialog.

6.7.4 View the water balance output

- On the Result tab, select the sub-item for the Chart output
- Click on the Open button beside the file path to create and open the water balance graphic
- To compare the water balance with abstraction to that without abstraction repeat the same procedure for the model run without abstraction



The water balances show that during the simulation period a total of 14 mm is abstracted. 7 mm is taken from saturated storage (storage change) and the remainder causes a reduction in baseflow of 1 mm and drain flow of 6 mm compared to natural conditions.

Additional optional exercise: Play around with the different water balance options to see how baseflow, drain flow and saturated zone storage may be changing over time due to abstraction.



Note that the water balance items are all normalised to units of mm, which allows for easy comparison between the different components. If you want to convert depths of mm to volumes, you need to multiply the depth by the internal model area. That is, the total model area minus the area of the outer boundary cells.

An easy way to calculate the internal model area is to load the pre-processed data into the Grid Editor, select the Model and Domain item. Then, you can use the statistics function in the Grid Editor to find out the number of internal (Grid Code = 1) versus boundary cells (Grid Code = 2).

End of the Exercise